

INSTRUCTION MANUAL

SF9705HC Hair Clipper

Sharp Modes 



HB-0002



sanford[®]
TOUCHING YOUR LIFE EVERYDAY







The "SANFORD" trademark of hair clipper are highlight of its nice appearance, super power, easy operating and low noise. We are sure that this unit will correspond to the highest requests for the quality and will become the real reliable supporter to the profession barbers. Before starting using this clipper please carefully read the instruction manual and comply with the rules Of using. In this case the trademark SANFORD will assure the long life of the equipment you have bought .Thank you for choosing SANFORD

No:1Frame draft

1.Outline



2.Accessories



NO: 2.Using instructions.

1.Your clipper was examined to ensure that the blades were oiled and aligned before leaving the factory.

2. Add a few drops of oil to the blades, turn clipper on for a few seconds before trimming. Then turn off and unplug it, using the damp cloth to wipe the clipper body to avoid that the oil spatter on people's hair. Loosen screws slightly and adjust the blade, tighten screws after blade is aligned.
3. When turn on or off the clipper while it is using there are some "de-de" noise with a bit heating and vibration. Please don't worry. This is the normal phenomenon and don't effected the clipper performance.
4. please always keep the clipper clean and usually drop oil to lubricate the blade
5. After replacing or cleaning the blades which should be alignment again. point for point

NO: 3. Instruction for hair cutting

The clipper had been adjusted to the best working condition and designed to be used in 220-240V~50-60Hz voltage range before leaving the factory.

They have some strong noise when having a high voltage while the clipper is operating.



At this time you just need the equipped tap lever to loosen the adjust screw in anti-clockwise direction until decline down the noise. When having a low voltage the clipper blade with less power and narrow moving range, at this condition you just need to do the opposite operation to above.

NO: 4. Blade alignment

Blades must be realigned if they have been removed for cleaning or replacement; or blade alignment is incorrect. The adjustment steps are as below:

1. while aligning the blade position please using the screwdriver to loosen the underside blade fix screws and make sure the upper and under blade teeth up ,fixed on and point for point. Then tighten at last.

2.To realign the blades, simply match the upper and bottom blades teeth up the end of top blade teeth should be approximately 1.2mm back from bottom blade in case of shearing skin

3.The leftmost tooth of the upper blade should cover up to the first left tooth of the under blade; the rightmost tooth of the upper blade should cover up to the rightmost tooth of the under blade.



NO: 5.Lubrication

1.Please add a few drops of oil between the cutting blade teeth before clipping.

2.Add a few drops of oil to the blades, after alignment or cleaning or replacing the clipper blades. Then turn clipper on for

a few seconds to make sure the blades are being oiled.

3.The clipper up blade with high frequency moving speed while it is operating. Do not use hair oil, grease, oil mixed with kerosene or any solvent without the special lube, as they may evaporate and leave thick oil which will slow own blades motion.



NO: 6.Blade lever

The un-adjustable hair clipper

The un-adjustable hair clipper through using the attached spacing comb accessories to adjust the being out hair length (spacing comb size with 3mm, 6mm, 9mm, 12mm)

The adjustable hair clipper

1. The adjustable hair clipper through changing the tap lever position to adjust the being cut hair length

2.The tap lever is located near your thumb so it can be easily adjusted while the clipper is on your right- hand.

3. When the tap lever is in uppermost position, the blades will give you the closest cut and leave the hair very short. Pushing the lever downward gradually increases the cutting length.
4. In addition, if extremely heavy hair cutting has jammed the blades. It will help you remove hair that has become wedged between the two blades without removing the blades. While the clipper is running, rapidly move the lever from "close cut" to "longer cut" a couple of times. Doing this each time after you have finished using your clipper will help to keep the blades clean of cut hair.



NO: 7. Cleaning & Care

1. Using a clean damp cloth to wipe the clipper body and using the attached cleaning brush to sweep the cut short hair or dust which wedged between the blade teeth. Doing this each time after you have finished using your clipper and then drop oil on the blade.
2. Please store your clipper in the dry environment to extend the using life
3. After the long time using the blade will be dulled and will decline the cutting performance. In this condition please replace them with the new blades.



NO: 8. Safety Precautions

1. Unplug the appliance before cleaning.
2. Don't use while bathing or in shower.
3. Don't touch this unit that has fallen into water. Unplug immediately!!
4. Use this unit only for its intended use. Do not use attachments not recommended by the manufacturer.
5. Before using, make certain blades aligned properly.
6. Don't use the appliance with damaged comb or with missing teeth, it may cause injury.
7. Have any problem with this unit should ask for help to the electrical engineer or contact the manufacture immediately. Please don't open the body cover to repair it by unauthorized.

ان ملكية الحلاقة من سافورد تتميز بشكلها الانيق وال جذاب وقوتها وسهولة التشغيل والاستعمال وضوضاء منخفضة للغاية ونحن في سافورد نعتقد بما لا يدع مجالاً للشك من هذا الماكينة بتصميمها الرائع والقوي هذا ستكون خير داعم وحليف للحلاقين المحترفين والهواة معاً، والاستخدام طويل وأمن نرجوا منكم قراءة دليل الاستخدام المصاحب للماكينة قبل استعمالها لتكون لكم اختياركم لسافورد.

أولاً: الاطار الخارجي

1. الاساسيات:



2. المكونات:



ثانياً: طريقة الاستخدام

1. تم اختبار وتزييت الماكينة والتأكد من انتظام شفرات الحلاقة وحالتها المناسبة لاستخدامات الحلاقة قبل مغادرتها مصنع سانفورد.
2. يمكنك من اضافة نقاط قليلة من الزيت لتزييت اسنان شفرات الماكينة ثم تشغيلها لتواني قليلة ثم قفلها لانتسي تنظيف الماكينة من بقاء التزييت بقطعة قماش نظيفة حتي لا تسقط علي شعر الزبون، ويمكنك أيضاً من ضبط الشفرات بواسطة مسمار الربط ومن ثم تأكد من اغلاقه بعد الضبط وبذلك تكون الماكينة جاهزة للاستخدام والحلاقة.
3. عند تشغيل او قفل الماكينة سوف تسمع صوت "دي . دي" مع بعض السخانة والاهتزاز ويعتبر هذا عاديا ولا يؤثر علي امكانيات الماكينة.
4. يفضل الابقاء باستمرار علي الماكينة نظيفة كما يفضل اضافة نقاط قليلة من الزيت لتزييت الشفرات.
5. عند نظافة او تغيير الشفرات يجب التأكد من تراصف الشفرات واحدة واحدة.

ثالثاً: ارشادات الحلاقة.

ان ماكينة الحلاقة من سانفورد صممت علي افضل حالة للتشغيل كما صممت علي كهرباء ذات جهد 220 فولت وتردد 50 هيرتز قبل مغادرتها المصنع، في بعض الاحيان عندما تكون الكهرباء اعلي من جهد الماكينة تصدر



الماكينة صوت ضوضاء بكل بساطة يمكن من عمل ارتخاء لمسمار الربط في اتجاه عكس عقارب الساعة حتي تتوقف الضوضاء ، وعندما تكون الكهرباء ضعيفة فان الماكينة يقل ادائها مع ضعف الحلاقة وكل ما يمكنك فعله هو ان تعكس ما قمت به اعلاه.

رابعاً: ترصيف الشفرات.

عند فك الشفرات لتنظيفها وتنظيف الماكينة او عند تغيير الشفرات يجب التأكد من ترصيف الشفرات وكذلك اذا اختلف ترصيف الشفرات لضبطها مجدداً عليك بالاتي:

1. عند القيام برصيف شفرات الماكينة قم بواسطة مفك بحل مسمار الربط للشفرات السفلي وقم بضبط الاسنان العليا واحدة بواحدة مع السفلي ثم اخيراً قم برط المسمار جيداً.
2. لاعادة ترصيف شفرات الماكينة يجب ضبط الاسنان العليا مع السفلي بحيث يكونا متساويين.
3. ترجع الشفرات السفلي حوالي 2 ملم اذا كانت تحدث قطع في جلد الرأس.
4. يجب عليك مراعاة ان أخرة سن شفرة عليا من الشمال تغطي اخر سن شفرة سفلي من الشمال وان اخر سن شفرة عليا من اليمين تغطي اخر سن شفرة سفلي من اليمين.



خامساً: التزيت.

1. يرجى وضع نقاط قليلة من الزيت بين اسنان الشفرات لتزيت الشفرات قبل البدء في عملية الحلاقة.



2. عند القيام باستبدال او نظافة او ترصيف الشفرات يمكنك من اضافة نقاط قليلة من الزيت لتزيت اسنان شفرات الماكينة ثم تشغيلها لتواني قليلة لتأكيد عملية تزيت جميع الشفرات.
3. قم فقط باستخدام انواع الزيوت المناسبة لماكينات الحلاقة لان انواع الزيوت الاخرى من شأنها ابطاء حركة شفرات الحلاقة وبالتالي اداء سيء للماكينة.

ساساً: روافع الشفرات.

تأتي ماكينة الحلاقة من سافورد ببعض المكونات المصاحبة كرافعات الشفرات لتعدد انواع الحلاقة ما بين خفيف الي كثيف (مرة 1 ومرة 2.. الخ) وهنا نتحدث عن المقاسات (3 ملم و6 ملم و9 ملم و12 ملم).

1. قم بتعديل رافعة الشعر حسب ما يطلبه الزبون بوضعها وتركيبها اسفل الشفرات السفلي.
2. ان مكان تثبيت رافعات مستويات الحلاقة بالقرب من ابهامك لذا يمكنك من تثبيتها بينما عي في يدك اليسري.
3. بتركيب اصغر الشفرات تحصل علي شعر قصير وبالضغط عليها تزيد من القطع.
4. من فوائد رافعات مستويات الحلاقة انها بإمكانها ازالة ال كثيف الذي يعلق علي الشفرات من جراء الشعر المجعد والكثيف من نون ان تزيل الشفرات وذلك بالتمير من القص القصير الي القص الطويل مرتين، فعليك هذا بعد نهاية



كل عملية حلاقة يجعل من الشفرات نظيفة وخالية من الشعر العالق
سابعاً: العناية ونظافة الماكينة.

1. قم بواسطة قطعة قماش نظيفة بتنظيف ماكينة الحلاقة وبواسطة الفرشاة المصاحبة من ازالة قصاصات الشعر والغبار العالق في شفرات الماكينة ثم بعد ذلك قم بوضع نقاط قليلة من الزيت لتزييت الشفرات، قم بهذا العمل كلما انتهيت من اداء عملية حلاقة ما.
2. قم بحفظ ماكينة الحلاقة الخاصة بك في مكان جاف لاطالة عمر استخدامها.
3. في حالة عدم الاستخدام لفترة طويلة يصبح اداء الشفرات ضعيفاً وفي هذه الحالة يجب استبدال الشفرات.

ثامناً: تنبيهات للسلامة.

1. افصل الماكينة من الكهرباء قبل عملية التنظيف.
2. لا تقم باستخدامها أثناء الاستحمام.
3. لا تقم بلمس الماكينة اذا وقعت في الماء، وقم بفصلها من الكهرباء فوراً
4. تستخدم هذه الماكينة فقط لما صنعت من اجله ويلزم استخدام المكونات المصاحبة من الشركة فقط.
5. قبل الاستعمال قم بتدريبات التشغيل جيداً.
6. لا تقم بتشغيل الماكينة بارتفاع شفرات تالفة او سن شفرة ناقصة
فذلك من شأنه جرح جلد الرأس.
7. لا تقم بمعالجة المشكلات التي تحتاج الي تدخل فني متخصص
بنفسك ولكن قم باخذ الماكينة الي فني متخصص او احد منافذ الخدمة
المعتمدة من قبل سالفورد.

- The appliances is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision of instruction.
- Children being supervised not to play with the appliance.
- Warning : keep the appliance dry

- لا يجب استخدام الجهاز بواسطة الاشخاص ذوي الاحتياجات الخاصة (بما فيهم الاطفال) ، او الاشخاص الذين يفتقدون الي الخبرة الكافية.
الا اذا اولوا الاشراف الكامل .
- يجب ان توضح التعليمات بان الاطفال لا يجب عليهم اللعب بهذا الجهاز.
- تحذير : احتفظ بالجهاز جافاً

Implementing Your expectations



sanford
TOUCHING YOUR LIFE EVERYDAY



Entertainment
Collection



White Goods



Kitchen
Collection



Home Appliances



Personal
Gadgets



Electric Collection



Luminous Collections

sanford®

Electronics &
Home Appliances

1500 Plus Products

www.sanfordworld.com | info@sanfordworld.com



Visit us on
www.sanfordworld.com

For more inquiry,
you may please write to us at
info@sanfordworld.com

صنع في الصين