

## INSTRUCTION MANUAL / WARRANTY CARD

### SF9954DMT

---

### Detachable Multi Toaster



1400  
Watts



**sanford**<sup>®</sup>  
TOUCHING YOUR LIFE EVERYDAY





(**CAUTION: Hot surface**): The surfaces are liable to get hot during use.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children less than 8 years.

## **IMPORTANT SAFEGUARDS**

When using electrical appliance, especially when children are present, basic safety precautions should always be followed, including the following:

1. Read all instructions before using.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord, plug or cooking unit in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors or for commercial purposes or industrial use.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

12. Always attach plug to appliance first, then plug cord in the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
13. Do not use appliance for other than its intended use.
14. Do not attempt to dislodge food when appliance is plugged in.
15. A fire may occur if appliance is covered or touching flammable material, including curtains, draperies, walls and the like, when in operation.
16. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
17. Children should be supervised to ensure that they do not play with the appliance.
18. This appliance is not intended to be operated by means of an external timer or separate remote-control system.
19. Do not operate the appliance with the upper lid opened.

## SAVE THESE INSTRUCTIONS!

This product is for **HOUSEHOLD USE ONLY**.

## POLARIZED PLUG INFORMATION

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

## SHORT CORD INFORMATION

A short power supply cord is provided to reduce the risk of becoming entangled in or tripping over a long cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the extension cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

1. Hot plate with high-temperature nonstick characteristics.
2. Power indicator shows a green light when the electric plug of the sandwich baker is put into a wall power outlet.
3. Ready indicator shows a red light when unit stops heating.
4. Handle with cool touch.
5. Buckle can lock unit when it is closed.
6. Unit can be stored upright to save space.
7. Non-slide feet can avoid the baker from sliding on a slope.

This sandwich maker incorporates detachable cooking plates. Choose your desired cooking plate for the task to be performed. Install the cooking plates as shown in the following illustration.



Open the sandwich maker



To remove, pull the tab outward to release the cooking plate, raise the heating plate upwards to remove it.



To install the cooking plate, place it in position. Make certain the slot of the cooking plate hooks with the hinge. Press the cooking plate down with a little force until a click sound is heard.

### On First Use Please Pay Attention to:

1. Clean the baking tray with a piece of damped cloth or foam rubber.
2. Gently apply butter or edible oil to the baking tray.
3. Put the electric plug into the wall outlet and turn on the power of the sandwich baker to heat the baking tray. You should wait for the automatic turn-off of the red light before you bake the food.

**Attention!** Slight smog will show on first use of the sandwich baker, and this is normal because the internal parts are heated for the first time.

### Preparing Sandwiches

1. Put the plug into the wall outlet, then the red light and as well as the green light will go .
2. The sandwich baker is ready for use after the red light automatically turns off.
3. Make ready your sandwich ingredients. For one sandwich use tow pieces of bread and a certain quantity of ingredients. You might refer to some recommended ingredients.
4. To achieve a golden color effect, you can apply some butter to the side of the bread on which the bread contacts the baking tray.
5. When placing the first pieces of bread, make sure that the side with the butter faces the lower baking tray. Load your ingredients and cover them with the second piece of bread with butter applied, and then you can make a satisfying sandwich. Place the ingredients well to get the ideal effect.
6. Lower the upper baking tray carefully and press it on the bread, then lock the handle clasp.
7. Open up the sandwich baker after heating it for 2-3 minutes to check if the sandwich has turned to the golden color you wanted. Control the baking period according to your taste.
8. Take out the sandwich with a non-metal tool. Do not use sharp or abrasive tools.
9. Unplug the electric plug after use.

**Attention!** The red light will be automatically turned on or off in a regular pattern during use, and the machine can control its temperature in a normal range.

## **After Use:**

1. Unplug the electric plug, and cool the machine before cleaning.
2. Clean the baking tray with a piece of damp cloth or foam rubber. Never immerse the product in water to avoid any water getting into the interior of the machine.
3. To avoid damaging the high-temperate nonstick characteristics of the baking tray never use abrasive cloth for cleaning.

- 1.waffle plate,
- 2 grill plate,
- 3 cookies plate
- 4.donut plate,
- 5 sandwich plate,
- 6 nutty plate

في درجة الحرارة في المعدل الطبيعي.

#### بعد الاستعمال:

1. افصل القابس الكهربائي، وتبريد الجهاز قبل التنظيف.
2. تنظيف صينية الخبز بقطعة من القماش مبللة أو المطاط الرغوي. لا تزعج المنتج في الماء لتجنب أي دخول للمياه إلى داخل الجهاز.
3. لتجنب وإزالة المواد اللاصقة قم بصب ماء معتدل لصينية الخبز ، لا تستخدم غير القماش للجلخ والتنظيف.

1. لوح البسكويت.
2. لوح شواء.
3. لوح الكعكات.
4. لوح الدونات.
5. لوح الساندويتش.
6. لوح الجوز.



إذا تم تطبيق الرعاية في استخدامها. إذا تم استخدام سلك التمديد، ووضع الموصل في سلك التمديد يجب أن تكون مرتبة بحيث لا يتم ثني على السلك أو وضعه تحت الطاولة ، ويجب ان يكون بعيدا عن الأطفال منعا من التعثر دون قصد.

1. لوح التسخين مع مواد غير لاصقة ودرجة تسخين عالية.
  2. مؤشر الطاقة يظهر ضوءاً أخضر عندما يتم وضع قابس صانع الساندويتش بمأخذ الطاقة.
  3. مؤشر الطاقة يظهر الضوء الأحمر عندما يتوقف عن العمل (التسخين).
  4. المقبض للمسا بارد.
  5. عن طريق المشبك يمكن تأمين الوحدة بعد اغلاقها.
  6. يمكن تخزين الوحدة بشكل مستقيم لتوفير مساحة.
  7. الوحدة بها ارجل لمنعها من الانزلاق.
- يتضمن صانع الساندويتش هذا لوحات الطبخ قابلة للانفصال. قم باختيار لوحة الطهي المطلوبة للمهمة التي يتعين القيام بها، تثبيت لوحات الطبخ كما هو مبين في الرسم التوضيحي التالي.



إزالة، يجب سحب الزر الموضح إلى الخارج لفتح لوحة الطهي، ورفع لوحة التسخين صعودا حتى



فتح صانع الساندويتش  
إزالته.



لتثبيت لوحة الطهي، وضعه في بوضع جيد بحيث تتناسب الفتحات مع السنانير. اضغط على لوحة الطبخ من أسفل مع قوة صغيرة حتى يتم سماع صوت نقرة.



10. لا تضعه في أو بالقرب من موقد الغاز الساخن أو الموقد الكهربائي، أو في فرن ساخن.
11. يجب توخي الحذر الشديد عند تحريك أحد الأجهزة التي تحتوي على الزيت الحار أو غيرها من السوائل الساخنة.
12. دائما نصف المكونات إلى الجهاز أولاً، ثم نغم بتوصيل السلك في مقبس الحائط. ولقطع، وتحويل أي تحكم علينا وضع مفتاح التشغيل في وضع "إيقاف"، ثم إزالة الموصل من مقبس الحائط.
13. لا تستخدم الجهاز لأغراض أخرى غير الاستخدام المقصود منه.
14. لا تحاول إزالة المواد الغذائية عندما يتم توصيل الجهاز بالقابس.
15. قد يحدث اشتعالاً إذا لامس الجهاز مواد قابلة للاشتعال، بما في ذلك ستائر، الجدران وما شابه ذلك، عندما يكون قيد التشغيل.
16. ليس القصد من هذه الأجهزة للاستخدام من قبل أشخاص (بمن فيهم الأطفال) مع انخفاض القدرات المادية والحسية أو العقلية، أو عدم وجود الخبرة والمعرفة، ما لم تكن قد أعطيت لهم تعليمات أو الإشراف بشأن استخدام الأجهزة من قبل الشخص المسؤول عن سلامتهم .
17. يجب أن يكون الأطفال تحت الإشراف للتأكد من أنهم لا يعبثون مع الجهاز.
18. ليس القصد من صنع هذه الأجهزة ليتم تشغيلها بواسطة جهاز توقيت خارجي أو نظام مستقل للتحكم عن بعد.
19. لا نغم بتشغيل الجهاز والغطاء العلوي مفتوح.

**أحتفظ بهذه الارشادات!**

**هذا المنتج هو للاستخدام المنزلي فقط.**

**معلومات عن القابس المستقطب**

هذا الجهاز به قابس مستقطب (الشفرة الواحدة هي أوسع من الأخرى). للحد من خطر حدوث صدمة كهربائية، الغرض من هذا القابس أن يلائم بشكل كامل مع المخرج، عكس اتجاه القابس. إذا كان لا يزال لا يصلح، باتصال كهربائي مؤهل. لا تحاول تعديل القابس بأي شكل من الأشكال.

**معلومة عن سلك التيار القصير**

يتم صنع سلك التيار الكهربائي قصيراً للحد من مخاطر التعثر على السلك الطويل. ويمكن استخدام أسلاك التمديد

## عند الاستخدام الاول يرجى الانتباه إلى:

1. تنظيف صينية الخبز بقطعة من القماش المبللة أو المطاط الرغوي.
  2. قم باضافة الزبدة أو زيت الطعام لصينية الخبز.
  3. وضع القابس الكهربائي في مقبس الحائط وتشغيل الطاقة في صانع الساندويتش لتسخين صينية الخبز. يجب عليك الانتظار حتى يضيء المؤشر الاحمر وبعدها يمكن اخذ الطعام (الخبز).
- انتباه! وسوف يظهر دخان طفيف عند الاستخدام الأول من صانع الساندويتش ، وهذا أمر طبيعي لأن الأجزاء الداخلية تسخن لأول مرة.**

## إعداد السندويشات

1. وضع القابس في مقبس الحائط، ثم يضيء الضوء الأحمر وسينتقل بعدها الي الضوء الأخضر.
2. صانع الساندويتش جاهزا للاستخدام بعد ان يتحول الضوء الأحمر تلقائيا.
3. وأعدوا مكونات الساندويتش الخاصة بكم. لصناعة ساندويتش واحد اسحب قطعة من الخبز وكمية معينة من المكونات. قد أشير إلى بعض المكونات الموصى بها.
4. لتحقيق تأثير اللون الذهبي، يمكنك وضع بعض الزبدة إلى جانب الخبز الذي بصينية الخبز.
5. عند وضع القطع الأولى من الخبز، تأكد من أن الجانب البه زبدة يواجه الجزء التحت من صينية الخبز اضف عناصرك وغطها بقطعة ثانية من الخبز مع اضافة الزبدة، وبعد ذلك يمكنك صنع ساندويتش لذيذا. ويجب وضع المكونات جيدا للحصول على التأثير المثالي.
6. انزال صينية الخبز العليا بعناية واضغط عليه دون التأثير على الخبز، ثم اقفل قفل المقبض.
7. فتح صانع الساندويتش بعد تسخينه لمدة 2-3 دقائق للتحقق مما إذا تحولت الساندويتش للون الذهبي يمكنك السيطرة على فترة الخبز وفقا لذوقك.
8. اخراج الساندوتش بأداة غير معدنية. لا تستخدم أدوات حادة في ذلك.
9. افصل القابس الكهربائي بعد الاستخدام.

**انتباه! سيتم تشغيل الضوء الأحمر تلقائيا أو إيقاف تشغيله في نمط منتظم أثناء الاستخدام، ويمكن للالة التحكم**



(تنبيه: السطح ساخن): السطح عرضة للحصول على الحرارة أثناء الاستخدام.

هذه الأجهزة يمكن استخدامها من قبل الأطفال الذين تتراوح أعمارهم بين 8 سنوات فما فوق والأشخاص الذين يعانون من انخفاض القدرات الجسدية أو الحسية أو العقلية أو نقص الخبرة والمعرفة إذا ما أعطيت لهم تعليمات بشأن استخدام الأجهزة بطريقة آمنة والإشراف وفهم المخاطر. اما الأطفال يجب ان لا يعبثو بالجهاز. لا يجب إخضاع وتنظيف وصيانة الجهاز من قبل الأطفال إلا إذا كانوا من كبار السن من 8 فما فوق مع الإشراف. والحفاظ على الأجهزة والسلك الموصل بعيدا عن متناول الأطفال أقل من 8 سنوات.

تحذير: السطح عرضة للحصول على حرارة عالية أثناء الاستخدام.

#### إجراءات سلامة مهمة:

عند استخدام الأجهزة الكهربائية، فإننا نطلب منك قدرا من الحذر وخصوصا الأطفال عند استخدام أي جهاز كهربائي وبما في ذلك الالتزام بما يلي:

1. قراءة جميع التعليمات قبل استخدام.
2. لا تلمس الأسطح الساخنة. استخدام مقابض اليد.
3. للحماية ضد الصدمات الكهربائية لا تزج السلك الموصل، والمكونات أو وحدة الطهي في الماء أو السوائل الأخرى.
4. الإشراف الدقيق ضروري عندما يتم استخدام الجهاز من قبل أو بالقرب من الأطفال.
5. افصل الجهاز من مأخذ التيار عندما لا يكون قيد الاستعمال وقبل التنظيف. السماح له حتى يبرد قبل اللمس أو فك أجزائه وقبل التنظيف.
6. لا تشغل أي جهاز مع سلك تالف أو المكونات و بعد تعطل الأجهزة و تضررها بأي شكل من الأشكال. ارجاع الجهاز لأقرب مركز خدمة معتمد للفحص والإصلاح أو التعديل الكهربائي أو الميكانيكي.
7. قد يسبب استخدام المرفقات الملحقة التي من خارج الشركة المصنعة الغير محسنة في وقوع إصابات.
8. لا تستخدم في الهواء الطلق أو لأغراض تجارية أو استخدام الصناعي.
9. لا تدع السلك يخيم على حافة الطاولة أو المنضدة، أو لمس الأسطح الساخنة.

Thank you for purchasing **sanford** products, for the sake of excellent quality of our products, we certify that **sanford** products on this warranty are free of defect in material and workmanship and the end user is entitled to this warranty subject to the terms and conditions listed below.

- (1) The warranty will only be effective only if the warranty card is completed and returned to the company for the registration within 14days from the date of purchase, failing which might diminish the rights of warranty.
- (2) No other express warranty either written or oral is applicable to this product. THE DUARATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCAHNNTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. WE SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVINIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY APPLICABLE TO THIS PRODUCT.
- (3) The warranty covers product failure only. If any product is found defective, **sanford** will at its option, repair the product in question. Any replaced parts will become the company's property.
- (4) The warranty does not apply to/if (a) the accessories provided with the product (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage form accidents, lighting, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **sanford**. (f) the type of the product is defaced, removed, altered, deleted or render illegible.
- (5) The company will not be liable for any loss directly or indirectly caused from breakdown of the equipment, also for any delay in repairing the set due to non-availability of components.
- (6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.
- (7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.
- (8) **sanford** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.

SANFORD MIDDLE EAST DWC LLC  
Plot WF 01 & 02, Dubai Logistics City  
Dubai World Central, Dubai South,  
Dubai, United Arab Emirates,  
P O Box 90196  
Tel: +971 4 8824396 , Fax: +971 4 8820960

affix  
stamp


# sanford®

THIS PRODUCT IS FOR DOMESTIC USE ONLY

## LIMITED WARRANTY

**sanford** here by warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, **sanford** will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

### WARRANTY PERIOD

PRODUCT	MODEL	DIVISION	LABOUR
 <b>Detachable Multi Toaster</b>	<b>SF9954DMT</b>	Personal or non-income producing Use:	2 Years
		Commercial or income producing Use:	90 Days

The information obtained from you may be used by **sanford** or its affiliated companies for the purpose of direct mail including product information and/or special offers.

# sanford®

## END USER'S COPY WARRANTY REGISTRATION CERTIFICATE

### PERSONAL DETAILS:

Mr/Mrs/Ms\* First Name: \_\_\_\_\_ Last Name: \_\_\_\_\_

Address: \_\_\_\_\_

Residence Tel No: \_\_\_\_\_ Office Tel No: \_\_\_\_\_ Mobile No: \_\_\_\_\_

Dealer Name : \_\_\_\_\_ Dealer Address: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Invoice No: \_\_\_\_\_

Product Name : **Detachable  
Multi Toaster** Model No: **SF9954DMT** Serial No: \_\_\_\_\_

Dealer's Stamp :

[Please mail back within 14 days from the date of purchase]

# Implementing Your expectations



**sanford**<sup>®</sup>  
TOUCHING YOUR LIFE EVERYDAY



Entertainment  
Collection



White Goods



Kitchen  
Collection



Home Appliances



Electric Collection



Personal  
Gadgets



Luminous Collections

# sanford<sup>®</sup>

Electronics &  
Home Appliances

## 1500 Plus Products



## UNITED ARAB EMIRATES

HEAD OFFICE  
**SANFORD MIDDLE EAST DWC-L.L.C**  
Plot WF 01 & 02, Dubai Logistics City  
Dubai World Central, Dubai South,  
Dubai, United Arab Emirates,  
P O Box 90196  
Tel:+971 4 8824396 , Fax:+971 4 8820960  
E-Mail: sanfordr@emirates.net.ae

**A.T.M.M. ELECTRONICS L.L.C (SANFORD)**  
# 105, 1st floor, Rashid Al Rashid Yateem Building  
P.O.Box: 90196, Clock Tower, Deira, Dubai, U.A.E  
Tel: +971 4 2953686, Fax: +971 4 2941334  
E-Mail: sanfordr@emirates.net.ae

**SANFORD TOUCH GENERAL TRADING**  
Murshid Bazaar, Deira, Dubai, U.A.E  
Tel: +971 4 2352043, Fax: +971 4 2352045  
www.sanfordtouch.com / info@sanford.ae

**SANFORD TOUCH GENERAL TRADING(BR)**  
Murshid Bazaar, Deira, Dubai, U.A.E  
Tel: +971 4 2256008, Fax: +971 4 2256009  
www.sanfordtouch.com / info@sanford.ae

**SANFORD TRADING L.L.C**  
P.O.Box: 90196, Murshid Bazaar, Deira, Dubai, U.A.E  
Tel: +971 4 2351567, Fax: +971 4 2351569

**IZAAN GENERAL TRADING L.L.C**  
Murshid Bazaar, Deira, Dubai  
Tel: +971 4 2266903, Fax: +971 4 2252923

**ABDULLAH MOHAMED HOME APPLIANCES TRADING CO L.L.C**  
P.O.Box: 90196, Near Irani Souq, Deira, Dubai, U.A.E  
Tel: +971 4 2265048, Fax: +971 4 2263677

## QATAR

**DOHA STAR TRADING CO. W.L.L**  
II Floor, Al Ghanem Building, Near Karwa Bus Stand  
P.O.Box: 22390, Doha, Qatar  
Tel: +974 44312193, Off: +974 44312097, Fax: +974 44315817  
Web : www.dohastarqa.com / E-mail: info@dohastarqa.com

**AL SHABIB TRADING STORES**  
P.O.Box: 22390, Doha, Qatar  
Tel: +974 44422801, Off: +974 44312193, Fax: +974 44437593  
E-Mail: alshabib@qatar.net.ae

## KUWAIT

**AHMED FLAITAH AL-SHAMRY EST  
ELECTRICAL & ELECTRONIC INT. TRADING CO.**  
Al Qibla, Block 6 - Building 17, 2nd Floor  
Office # 2, C.R. NO: 93506, Office : +965 22645579  
Tel: +965 22479383, Fax: +965 22441298 / sanfordkwt@yahoo.com

## BAHRAIN

**SANFORD ELECTRONICS CO W.L.L**  
Shop # 18, Road #3: 372, Wali Al Ahad Avenue  
Near Aradous Hotel, Manama 304, Kingdom Of Bahrain  
Tel: +973 17251439, Fax: +973 17251438

## OMAN

**DELTA MUSCAT TRADING L.L.C**  
Post Box 60, Al Hamriya,  
Postal Code 131, Sultanate Of Oman  
Tel: + 968 24830168 , Fax: + 968 24830074  
e-mail: Sanford@omantel.net.om

## HONGKONG

**SOUTH FIELD GROUP COMPANY LTD**  
Room 2103, Easey Commercial Building  
253-261 Hennessy Road, Wanchai, Hong Kong  
Tel : 00852-2127 4570, Fax : 00852-2127 4571

**SANFORD CHINA CO. LTD**  
Room 2103, Easey Commercial Building  
253-261 Hennessy Road, Wanchai, Hong Kong  
Tel : 00852-2127 4570, Fax : 00852-2127 4571

## KINGDOM OF SAUDI ARABIA

**SHATEA AL GHADEER TRD. & CON. CO.**  
Khonaini building #8529, 4th Floor, Suite 1,  
Al Rabee 2nd Street, **Dammam**, KSA, CR.No. 2050073833  
Email:sanfordksa@sanford-me.com  
T. +966 13 8333 787, F. + 966 13 8333 096  
Service-centre:+966 55 9039111 (Hello Care)

**SHATEA AL GHADEER TRD. & CON. CO.**  
Lulu Ware House No:248  
Dar Ul Baida- Al-hair Road - **Riyadh**.

**SHATEA AL GHADEER TRD. & CON. CO.**  
Bin Ateef Ware House No:2  
South Corniche Road- Al Khumra- **Jeddah**.

**SHATEA AL GHADEER TRD. & CON. CO.**  
Sanayiya Rushoody (Buraidha North) Saalmiya  
**Buraidha-al Qassim**.

**SHATEA AL GHADEER TRD. & CON. CO.**  
Ware House No:14 - Sulaimaniyya  
Near Al Jouf International School, **Sakaka - Al Jouf**.

**SHATEA AL GHADEER TRD. & CON. CO.**  
Atwad-imam Muhammed Bin Saud Road  
Khamis Mushaith - **Abha**

## INDIA

**SANFORD JAPAN ELECTRONICS PVT LTD.**  
Door No.10/1144, First Floor, Taj Complex  
Wadakkanchery, Thrissur-680582, Kerala, India.  
Mobile : +918606208889, +91-8606168889

## JAPAN

**SANFORD JAPAN INDUSTRIAL CO., LTD**  
2-9-1-406, Motomachi, naniwa-ku, osaka, Japan  
Tel: 81 6-62103420

## CHINA

**SANFORD CHINA CO., LTD.**  
Guantian plaza , Room 414 - 416,  
No.6, Xing hua dong road, Ronggui shunde district  
Foshan city, China - 528305.  
Tel:+86075728312988.

## BANGLADESH

**SETU ENTERPRISE LTD**  
House #2, Lane #5, Road #01 , Block A,  
Halishahar H/e, Chittagong, Bangladesh .Tel: +88 01720234909  
setuenterprise.bangla@gmail.com

**SETU ENTERPRISE LTD**  
Sector No.8, Uttara Dhaka, Bangladesh, Tel : +880 1610 234909  
setuenterprise.bangla@gmail.com

## NEPAL

**VG PURE**  
Trade tower Nepal, 6th floor Thapathali, Kathmandu, Nepal.  
Tel: +977 9801210592 | Email: info@vgpure.com

## SRILANKA

**Brown & Company PLC**  
No: 481, T.B.Jayah Mawatha  
Colombo 10, Sri Lanka  
Tel: +94 11 26 63 000

## SANFORD INDUSTRIAL CO. LTD.

صنع في الصين