

sanford[®]
TOUCHING YOUR LIFE EVERYDAY

INSTRUCTION & WARRANTY BOOKLET



Electric Kettle

SF851EK - 1.0L



Scanning the QR code gives you access to your product's warranty registration and services.



EN ENGLISH

Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.



1800 Watts
220-240V~ 50-60Hz

Serial / Batch
No: 851082024



NB-0002

TABLE OF CONTENTS

- Please follow the notices in the Instructions Manual to assemble and use the product.
- Please read and understand the Instructions Manual and keep it properly for future reference.
- If you have any question in use, please contact online service in the required language.

SAFETY INSTRUCTIONS _____ 03

OPERATION GUIDELINES _____ 04

FEATURE _____ 05

CLEANING AND MAINTENANCE _____ 05

Thank you for buying this product. Please read and understand this manual carefully and keep it properly for convenience. The pictures in this instruction manual are for reference only, specifications are subject to the physical product.

SAFETY INSTRUCTIONS

1. This kettle is designed for domestic use only. No responsibility is accepted for damage resulting from improper use or non-compliance with the instructions.
2. The kettle is designed for heating water only. Never put any other liquid into the kettle nor should it use as another cooking appliance.
3. Before inserting the main plug into the socket whether the supply line voltage and current rating are in compliance with the rated electric parameter shown on the kettle label.
4. Do not operate the kettle with wet hands.
5. Keep children away from the kettle which is either in heating or filled with hot water.
6. Prevent from scaling water or steam.
7. Pour away the very first water boiled with this kettle. Then it is ready for use.
8. Do not touch any part of the kettle except the handle when kettle is fully filled with boiling water.
9. Pour out the boiling water, all at one time, so as to enable the temperature of kettle decline.
10. Remove the plug from the wall socket in following case.
 - after use
 - malfunction comes up
 - before cleaning
11. When removing the plug from the wall socket never pull on the power cord.
12. Regularly clean and scour out the kettle. But do not immerse the kettle or power base in water as it will damage the appliance.
13. Do not expose the kettle to rain or moisture.
14. To prevent damage to the power cord, do not let it pass over sharp comers or edges.
15. Do not operate the kettle if the kettle or power cord show any signs of damage the kettle has been dropped.
16. If repairs are needed, please send the kettle to qualified personnel.

17. This appliance is not intended for use by persons(including children)with reduced physical Sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction conceding use of the appliance by a person responsible for their safety.
18. Children should be supervised to ensure that they do not play with appliance.
19. This kettle must only be used with the power base supplied.
20. This appliance is recommended for household use only.
21. The heating element surface is subject to residual heat after use

OPERATION GUIDELINES

1. filling water

The capacity of filled water is limited by the ultimate line graduated on the water level scale. It should not be higher than the max line, nor lower than the minimum line.

On filling water, care should be taken to avoid water column flowing on the kettles outside surface.

2. Locating

Place the kettle on a suitable flat surface.

Never heat the kettle on any wet surface, do not allow water to penetrate the electrical parts inside the kettle.

Do not position the kettle on or near hot surface or near open flames.

3. Switching on

Insert the main plug on the power cord into the wall socket.

Please take care that the power cord must be well located and can not caught on by a passerby.

Push the restoring switch on

The red indicator lamp bright. It indicates that the kettle is in heating.

4. Boiling

- The kettle is automatically switch off several seconds after the water is boiling.
- The red indicator lamp goes out as switch off.

5. Restoring

- After the kettle has switched off, it will take about 15 minutes to cool down and the kettle can be switch on again by manual restoring.
- If the red indicator lamp still goes out after pushing the restoring switch. It may be the case that the temperature sensing controller is still in hot condition and time must be taken for re-operating the kettle.

FEATURE

1. Immersed heating tube with a stainless still plate under it.
2. Water level scale in metric & English systems and limit marks.
3. Three levels of appliance protection.
 - a) Temperature sensing controller-automatic switch-off when water is boiling.
 - b) Dry boiling protector-boil-dry safety cut off
 - c) Thermal fuse cut off the circuit if dry boiling protector fails.

WARNING: To prevent personal injury or electric shock, do not immerse electric kettle, power base, its cord or plug in water or other liquid.

CLEANING AND MAINTENANCE

- Make sure the appliance is unplugged from the supply socket and fully cooled down before cleaning.
- To clean the exterior surfaces, slightly wipe over with a soft damp cloth and dry thoroughly.
- To clean the inner walls of the kettle, use a soft cloth or soft brush to remove the dirt.

Note: Never use abrasive products

- Never immerse the kettle or its base in water.

WARRANTY INSTRUCTIONS

Thank you for purchasing SANFORD products, for the sake of the excellent quality of our products, we certify that **SANFORD** products are free of defects in material and workmanship, and the end-user is entitled to this warranty subject to the terms and conditions listed below.

(1) The warranty will be effective only if you receive a Confirmation/ Approval email and a warranty certificate from **SANFORD**.

(2) No other express warranty either written or oral is applicable to any product. THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. **SANFORD** SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS, OR ANY OTHER DAMAGES, DIRECT, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS APPLICABLE TO THIS PRODUCT.

(3) The warranty covers product failure only. If any product is found defective, **SANFORD** will at its option, repair the product in question. Any replaced parts will become the company's property.

(4) The warranty does not apply to/if (a) the accessories provided with the product. (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage from accidents, lightning, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **SANFORD**. (f) the type of the product is defaced, removed, altered, deleted, or rendered illegible.

(5) **SANFORD** will not be liable for any loss directly or indirectly caused by the breakdown of the equipment, also for any delay in repairing the set due to the non-availability of components.

(6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

(7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.

(8) Since the product is intended for domestic purposes only, the warranty will be void if used for commercial purposes. As part of our commitment to quality we offer a 3-month warranty for commercial usage.

(9) **SANFORD** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.

sanford

Warranty Period 2 Years

LIMITED WARRANTY

SANFORD hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, SANFORD will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

REGISTER YOUR NEW SANFORD PRODUCT FOR WARRANTY

Scanning the QR code gives you access to your product's warranty registration and services.



Step 1: Scanning the QR code gives you access to your product's warranty registration and services.

Step 2: Register the warranty by scanning the QR code or log on to <http://www.sanfordjapan.com/warranty.html> to access the warranty registration

Step 3: Fill out the Warranty Registration Form and submit the application after reading and agreeing to the terms and conditions.

Step 4: After successful registration, the page will display the notification message "Your entry has been submitted successfully!"

Our customer service department will verify the warranty registration within 7 days. If your warranty registration is approved, you will receive a Warranty Certificate email. Please keep the certificate to claim the warranty.

If your warranty registration is denied, you will receive an email from us explaining the reason for the rejection.

For more information, Call Toll-Free 800-7263673 (UAE)

Toll-Free 1800-4251163 (INDIA), +966 559039111 (KSA)

+968 9525 8453 (OMAN), +974 3343 7806 (QATAR)

Moreover you may write to sm-dwc@sanford-me.com and service@sanford-me.com or WhatsApp +971 543498627

سانفورج

تعيش تفاصيل يومك

مدة الضمان ٢ سنة

ضمان محدد

تضمن **سانفورج**، وفقاً للشروط والاحكام الموضحة بأنه في حال تعطل هذا المنتج بسبب سوء التصنيع او المواد المستخدمة حسب الفترة الموضحة ادناه، فإن **سانفورج** ستقوم بصيانة ذات المنتج، بما في ذلك كافة الاجزاء التي تأثرت من جراء هذا العطل دون أي رسوم مقابل الاجزاء او العمل.



قم بتسجيل منتج سانفورج الجديد خاصتك للحصول على الضمان

يمكنك مسح رمز الاستجابة السريعة إمكانية الوصول إلى تسجيل الضمان الخاص بمنتجك وخدمات الصيانة.

الخطوة ١ تسجيل المنتج عبر مسح رمز الـ كيو ار فونيا او الدخول على الرابط <http://www.sanfordjapan.com/warranty.html> من اجل الحصول على استمارة التسجيل **الخطوة ٢** املء استمارة التسجيل وقم بتقديمه بعد الاطلاع والموافقة على كافة الشروط والاحكام.

الخطوة ٣ بعد اتمام عملية التسجيل بنجاح، ستظهر لك هذا الرسالة: "لقد تم التقديم بنجاح".

الخطوة ٤ سيقوم قسم خدمة العملاء بمراجعة تسجيلك خلال ٧ ايام، في حال الموافقة على التسجيل الذي قمت به، ستصلك رسالة تحتوي على شهادة الضمان في بريدك الالكتروني. فضلاً احتفظ بعذة الشهادة للحصول على الضمان. في حال قبول تسجيلك بالرفض، ستصلك رسالة لتوضيح اسباب الرفض.

للمزيد من المعلومات، يرجى الاتصال بالرقم المجاني 800 7263673 (الامارات العربية المتحدة)

الرقم المجاني 18004251163 (الهند)، +966 559039111 (المملكة العربية السعودية)

+968 9525 8453 (عمان)، +974 3343 7806 (قطر)

كما بإمكانك ان تراسلنا على البريد الالكتروني: sm-dwc@sanford-me.com وكذلك: service@sanford-me.com

او على رقم الواتساب: +971 543498627

5. التخزين

- بعد انطفاء الغلاية ستحتاج الى 15 دقيقة حتى تبرد تماما ويمكن تسغيل الغلاية مرة اخرى بالتشغيل اليدوي
- اذا لم تضىء لمخبة الشارة الحمراء ربما يعود ذلك الى ان حساس الحرارة مايزال ساخنا لذلك يجب عليك منحه بعض الوقت.

خصائص

1. انبوب تسخين مخبأ فوق صحن فولاذي
 2. مستوى الماء موضح بالقياسات باللغة الانجليزية.
 3. ثلاثة مستويات للحماية
- (ا) نظام قفل الي للتحكم في حساس الحرارة عند غليان الماء

(ب) نظام حماية عند خلو الغلاية من الماء

(ج) فصل صمام منظم الحرارة عند فشل نظام الحماية عند خلو الغلاية من الماء.

تحذير : لتفادي الاصابة بصدمة كهربائية، لا تغمر الغلاية، سلك الكهرباء او القاعدة او الفيشة في الماء او في اي سائل اخر

التنظيف والعناية

- تاكد من فصل الجهاز عن الكهرباء قبل تنظيفه.
- لتنظيف الجزء الخارجي، قم بمسحه بقطعة قماش ناعمة ورطبة ثم جفف جيدا
- لتنظيف الجزء الداخلي، استخدم قطعة قماش ناعمة لازالة الاوساخ.
- ملاحظة : لا تستخدم المواد القاشطة
- لا تغمر الغلاية او القاعدة في الماء.

17. لا يجب استخدام الغلاية بواسطة اشخاص ذوي اعاقات جسدية او عقلية (بمافي ذلك الاطفال) او الاشخاص الذين ليس لديهم خبرة الا اذا تم الاشراف عليهم.
18. يجب الاشراف على الاطفال في حال استخدامهم للغلاية وضمان عدم اللعب بها.
19. يجب توصيل الغلاية بالمقبس الرئيس للكهرباء
20. يجب استخدام الغلاية للاغراض المنزلية فقط.
21. يظل سطح عنصر التسخين ساخنا حتى بعد الانتهاء من استخدام الجهاز

ارشادات الاستخدام

1. ملأ الماء

- الحد الاقصى للماء تم توضيحه بواسطة الخطوط المرسومة على الغلاية ولا يجب تخطيها او المبالغة في تنقيص الماء.

- كن حذرا عند ملأ الماء حتى لا ينسكب على الجدار الخارجي للغلاية.

2. الوضعية

- ضع الغلاية على سطح مستو وجاف

- لا تسخن الغلاية على سطح مبلل. لا تدع الماء يتغلغل الى الاجزاء الالكترونية داخل الغلاية.

- لا تضع على سطح ساخن او بالقرب من شعلة نار

3. التشغيل

- قم بايصال السلك بالمقبس الرئيس على الجدار.

- توخى الحذر في توثيل لسلك وتاكد من عدم اعتراضه لمر مشاة

- اضغط على زر الشتغيل

ستضىء لمبة التشغيل اشارة الى ان الغلاية تعمل الان.

4. الغليان

- ستنتطفئ الغلاية بعد عدة ثواني من الانتهاء من غلي الماء.

- سنطفئ لمبة الاشارة

ارشادات السلامة

1. تم تصميم هذه الغلاية للاستخدام المنزلي فقط. الشركة المصنعة لا تتحمل مسئولية الاضرار الناتجة عن الاستخدام غير الصحيح او عدم الامتثال الى التعليمات.
2. تم تصميم الغلاية لتسخين الماء فقط. لا تضع ي سائل اخر داخل الغلاية ولا تستخدمها مع جهاز طبخ اخر .
3. قبل ان توصل الفيشة بالمقبس الرئيس ، تاكد من مطابقة قمية الجهد الكهربائي للغلاية والذي تم توضيح على الملصق مع الجهد الكهربائي للمصدر الرئيس للطاقة.
4. لا تشغل الغلاية وبيدك مبتلتان.
5. لا تدع الاطفال بالقرب من الغلاية، وهي في حال الغليان او تحتوي على ماء يغلي.
6. ابعد عن الماء الحار او البخار.
7. اسكب الماء الذي قمت بغليه لاول مرة مستخدما هذه الغلاية بعيدا وبعد ذلك، تصبح جاهزة للاستعمال.
8. لا تحاول لمس اي جزء من الغلاية ماعدا المقبض في حال احتوائها على ماء يغلي.
9. اسكب الماء الذي يغلي دفعة واحدة خارج الغلاية لتسمح للغلاية كي تبرد.
10. افصل السلك عن الكهرباء في الحالات التالية
- بعد الاستعمال
- في حال حدوث تلف ما
11. لا تسحب من السلك عند فصلك له عن الكهرباء.
12. قم بتنظيف الغلاية وتطهيرها دوريا ولكن لا تغمر الغلاية او سلك الكهرباء في الماء لان ذلك يضر بالجهاز.
13. لا تعرض الغلاية للمطر او الرطوبة.
14. لتفادي الاضرار بسلك الكهرباء، لا تدعه يمر عبر زوايا حادة.
15. لا تشغل الغلاية اذا
- في حال تلف في سلك الكهرباء
- في حال سقوط الغلاية
16. اذا كانت الغلاية في حاجة الى صيانة، فضلا قم بارسال الجهاز الى شخص مؤهل.



تعليمات وكتيب الضمان

سانفورد

تعيش تفاصيل يومك



غلاية كهربائية

اس اف ٨٥١ اي كي

يمكنك مسح رمز الاستجابة السريعة
امكانية الوصول الى تسجيل الضمان الخاص
بمنتجك وخدمات الصيانة.



قبل البدء في التركيب، اقرأ هذه التعليمات جيدا. ان اتباع هذه التعليمات
سيسهل عملية التركيب بالشكل الامن والصحيح. اترك كتيب التعليمات
بالقرب من المنتج للاطلاع عليها لاحقا.



AR ARABIC



NB-0002

1800 Watts | Serial / Batch
220-240V~ 50-60Hz | No: 851082024



www.sanfordjapan.com | info@sanfordworld.com | صنع في الصين