

Blender

SF6809BR

Scan this QR code and register for the warranty within 14 days of the purchase.



Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.

EN ENGLISH



600 Watts
220-240V~50/60Hz

Serial / Batch
No: 6809112022

TABLE OF CONTENTS

- Please follow the notices in the Instructions Manual to assemble and use the product.
- Please read and understand the Instructions Manual and keep it properly for future reference.
- If you have any question in use, please contact online service in the required language.

KNOW YOUR BLENDER	03
IDENTIFICATION OF PARTS	03
IMPORTANT SAFETY INSTRUCTIONS	03
BEFORE USING FOR THE FIRST TIME	04
SHORT-TERM OPERATION	04
OPERATION	04
GENERAL CARE AND CLEANING	05
DISPOSAL	05
CAUTION	05
TECHNICAL PARAMETERS	06
WARRANTY INSTRUCTIONS	07

Thank you for buying this product. Please read and understand this manual carefully and keep it properly for convenience. The pictures in this instruction manual are for reference only, specifications are subject to the physical product.

KNOW YOUR BLENDER

CAUTION: Follow these important steps to assemble, tighten, and mount blender container quickly and correctly. INJURY MAY RESULT IF MOVING BLADES ARE ACCIDENTALLY EXPOSED.

For Blender: The maximum operating time is 60 SEC of each use then the appliance to cool down for 1 MIN. after each use.

IDENTIFICATION OF PARTS



IMPORTANT SAFETY INSTRUCTIONS

The appliance may only be used by persons with reduced physical, sensory or mental capabilities, or lacking experience and knowledge, if they have given supervision or instruction concerning the use of the appliance and fully understand all dangers and safety precautions involved.

Children must not be permitted to operate the appliance. The appliance and its power cord must be kept well away from children.

Children must not be permitted to play with the appliance.

CAUTION: Keep any packaging materials well away from children-these materials are a potential source of danger, e.g. of suffocation.

Before the appliance is used, the main body as well as any attachments should be checked thoroughly for any defects. If the appliance, for instance, has been dropped onto a hard surface, it must no longer be used: even invisible damage may have adverse effects on the operational safety of the appliance.

The power cord should be regularly examined for any signs of damage.

In the event of such damage being found, the appliance must no longer be used.

The appliance should only be placed on a level surface.

DO NOT allow the housing or its power cord to come into contact with open flames or any hot surfaces such as hot-plates.

DO NOT let the power cord hang free.

DO NOT leave the appliance unattended while connected.

Always remove the plug from the wall socket, even if you leave the room Only for a short while

CAUTION: the blade is extremely sharp. To prevent injuries, take special care When cleaning the appliance and when emptying the blender jug.

DO NOT touch any moving parts during operation-this can be extremely dangerous.

CAUTION: do not put hot liquid into the blender jug.

Always switch the appliance off and remove the plug from the wall socket, Before opening the lid, before removing or fitting the blender jug, Before cleaning, in case of any malfunction during use, after use.

When removing the plug from the wall socket, never pull on the power cord; always grip the power cord; always grip the plug itself.

CAUTION: Any misuse can cause severe personal injury. No responsibility will be accepted if damage results from improper use, Or if these instructions are not complied with

BEFORE USING FOR THE FIRST TIME

Before the appliance is used for the first time, the blender jug and the lid should be thoroughly cleaned as described in the section General Care and Cleaning.

SHORT-TERM OPERATION

The appliance is designed to process average domestic quantities of food; It can be operated without interruption for a maximum of 60 seconds, after Which it should be allowed to cool down.

Before removing the blender jug, make sure that the rotary control is in position 0. This also applies when fitting the blender jug to the motor housing. if the control is not in its off-position(0),the motor will start immediately.

OPERATION

Put the liquid ingredients into the blender jug. The jug has a maximum capacity of 1250 ml. To avoid possible foaming or spilling when processing foamable or thin liquids such as milk, do not fill the jug over the 800ml mark.

DO NOT put any objects into the blender jug while the appliance is operating. Insert the plug into the wall outlet and use the rotary control to select the

required power setting.

CAUTION: do not operate when the blender jug is empty.

DO NOT fill it with dry items only, such as nuts, almonds etc.

After using the blender, switch off and remove the plug from the wall socket.

Wait until the motor has come to a complete standstill before removing the blender jug. Always wait until the motor has come to a complete standstill before taking the lid off.

GENERAL CARE AND CLEANING

Always remove the plug from the wall socket before cleaning the appliance.

To avoid the risk of electric shock,

DO NOT clean the motor housing or the power cord with water and do not immerse them in water.

The motor housing may be wiped with a slightly damp, lint-free cloth.

DO NOT use abrasives harsh for cleaning, and do not clean in a dish-washer.

For cleaning after use, fill the blender jug with approximately 100 ml warm water and a mild cleaning detergent. Let the appliance run for a short period as described in the section Operation. Then rinse the blender jug, lid and stopper with fresh water. All parts must be thoroughly dried afterwards.

DISPOSAL



This marking indicates that this product should not be disposed with other household Wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.

They can take this product for environmental safe recycling.

CAUTION

Do not immerse appliance in any liquids or water

If appliance is damaged please replace by the manufacturer, service agent or similarly qualified person to avoid hazard.

When appliance not in use unplug the power cord from power socket.

This appliance is not intended for use by person(including children)with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure they do not play with appliance.

Before operating the appliance be sure it is not placed on any uneven surface

Do not put your fingers or hands inside the blender during operation for your own safety.

TECHNICAL PARAMETERS

Model : SF6809BR

Power : 600 Watts

220-240V~ 50/60Hz

WARRANTY INSTRUCTIONS

Thank you for purchasing **SANFORD** products, for the sake of the excellent quality of our products, we certify that **SANFORD** products are free of defects in material and workmanship and the end-user is entitled to this warranty subject to the terms and conditions listed below.

(1) The warranty will be effective only if you receive a Confirmation/Approval email and a warranty certificate from **SANFORD**.

(2) No other express warranty either written or oral is applicable to any product. THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. **SANFORD** SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS, OR ANY OTHER DAMAGES, DIRECT, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS APPLICABLE TO THIS PRODUCT.

(3) The warranty covers product failure only. If any product is found defective, **SANFORD** will at its option, repair the product in question. Any replaced parts will become the company's property.

(4) The warranty does not apply to/if (a) the accessories provided with the product. (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage from accidents, lightning, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **SANFORD**. (f) the type of the product is defaced, removed, altered, deleted, or rendered illegible.

(5) **SANFORD** will not be liable for any loss directly or indirectly caused by the breakdown of the equipment, also for any delay in repairing the set due to the non-availability of components.

(6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

(7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.

(8) **SANFORD** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.



LIMITED WARRANTY

Warranty Period	2 Years
-----------------	---------

SANFORD hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, **SANFORD** will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

REGISTER YOUR NEW SANFORD PRODUCT FOR WARRANTY

The product must be registered for warranty within 14 days from the date of purchase. To register your product you'll need the model number, serial number and invoice.



STEP: 1

Register the warranty by scanning the QR code or log on to <http://www.sanfordjapan.com/warranty.html> to access the warranty registration form.

STEP: 2

Fill out the Warranty Registration Form and submit the application after reading and agreeing to the terms and conditions.

STEP: 3

After successful registration, the page will display the notification message "Your entry has been submitted successfully!"

STEP: 4

Our customer service department will verify the warranty registration within 7 days. If your warranty registration is approved, you will receive a Warranty Certificate email. Please keep the certificate to claim the warranty.

If your warranty registration is denied, you will receive an email from us explaining the reason for the rejection.

For more information, Call Toll-Free 800-7263673 (UAE)

Toll-Free 1800-4251163 (INDIA), +966 559039111 (KSA)

+968 9525 8453 (OMAN), +974 3343 7806 (QATAR)

Moreover you may write to sm-dwc@sanford-me.com and service@sanford-me.com or WhatsApp +971 543498627

sanford® | Warranty Registration

HOW TO OBTAIN THE REGISTRATION FORM?

OPTION 1 - By scanning QR code

Scan this QR code with your smart device

Warranty Form



سانفورد | تسجيل الضمان
تعيش تفاصيل يومك

كيف تحصل على استمارة التسجيل؟

الخيار الأول - عن طريق مسح رمز كيو ار ضوئيا بواسطة هاتفك السيار

ضمان محدد

تضمن سانفورد، وفقا للشروط والاحكام الموضحة بأنه في حال تعطل هذا المنتج بسبب سوء التصنيع او المواد المستخدمة حسب الفترة الموضحة ادناه، فان سانفورد ستقوم بصيانة ذات المنتج، بما في ذلك كافة الاجزاء التي تأثرت من جراء هذا العطل دون أي رسوم مقابل الاجزاء او العمل.

قم بتسجيل منتج سانفورد الجديد خاصتك للحصول على الضمان

يجب تسجيل هذا المنتج للحصول على الضمان خلال ١٤ يوما من تاريخ الشراء. من اجل تسجيل منتجك، عليك ارفاق رقم المنتج والرقم التسلسلي والفاتورة.

الخطوة ١

تسجيل المنتج عبر مسح رمز الـ كيو آر ضوئيا او الدخول على الرابط
<http://www.sanfordjapan.com/warranty.html>
من اجل الحصول على استمارة التسجيل



الخطوة ٢

املء استمارة التسجيل وقم بتقديمه بعد الاطلاع والموافقة على كافة الشروط والاحكام.

الخطوة ٣

بعد اتمام عملية التسجيل بنجاح، ستظهر لك هذا الرسالة: "لقد تم التقديم بنجاح".

الخطوة ٤

سيقوم قسم خدمة العملاء بمراجعة تسجيلك خلال ٧ ايام، في حال الموافقة على التسجيل الذي قمت به، ستملك رسالة تحتوي على شهادة الضمان في بريدك الالكتروني. فضلا احتفظ بهذه الشهادة للحصول على الضمان. في حال قبول تسجيلك بالرفض، ستملك رسالة لتوضيح اسباب الرفض.

للمزيد من المعلومات، يرجى الاتصال بالرقم المجاني 800 7263673 (الامارات العربية المتحدة)

الرقم المجاني 18004251163 (الهند)، +966 559039111 (المملكة العربية السعودية)

+968 84539525 (عمان)، +974 78063343 (قطر)

كما بإمكانك ان تراسلنا على البريد الالكتروني: sm-dwc@sanford-me.com وكذلك: service@sanford-me.com

أو على رقم الواتساب: +971 543498627

تعليمات التشغيل

شكرا لشرائك منتجات سانفور. من اجل ضمان الجودة لمنتجاتنا، نشهد بأن منتجات سانفور خالية من العيوب في مواد التصنيع والعمل وأن المشتري له الحق في الحصول على هذا الضمان وفقا للشروط التالية:

1. يكون الضمان ساريا فقط في حال تلقيك لرسالة تأكيد/موافقة من شركة سانفور عبر البريد الالكتروني.
2. لا يوجد ضمان صريح آخر سواء كتابي أو شفوي ينطبق على أي منتج. تقتصر مدة أي ضمانات بما في ذلك الضمان الضمني لقابلية التسويق على مدة الضمان الصريح الوارد في هذه الوثيقة. لا تتحمل شركة سانفور مسؤولية فقدان استخدام المنتج أو الإنزاع أو الخسارة أو أي أضرار أخرى ، مباشرة أو تكميلية ، ناشئة عن استخدام أو عدم القدرة على استخدام هذا المنتج أو عن أي خرق أو انتهاك صريح أو ضمني للضمان، بما في ذلك الضمان الضمني للتسويق، ينطبق على هذا المنتج.
3. يغطي هذا الضمان فشل المنتج في العمل فقط. في حال اكتشاف ان الجهاز يحتوي على عطل ما، ستقوم سانفور، تطوعا، بصيانة المنتج المذكور. اي اجزاء تم استبدالها تصبح ملكية خاصة بالشركة.
4. لا ينطبق هذا الضمان على أ. الملحقات التي تأتي مع المنتج ب. اعطال كهربائية. ت. عطل بسبب سوء الاستخدام أو الصيانة. ث. صيانة أو محاولة صيانة المنتج بواسطة شخص لا يملك الصلاحية. ج. عطل بسبب الحوادث أو البرق أو الماء أو الحريق أو سوء التهوية أو سوء الاستخدام أو التعديل أو لأي سبب خارج ارادة سانفور.
5. لا تتحمل سانفور مسؤولية فقدان بسبب تعطل الجهاز بشكل مباشر أو غير مباشر. كذلك، لأي تأخير في صيانة المنتج بسبب عدم توفر قطع الغيار.
6. يجب ارفاق فاتورة الشراء التي تحتوي على تاريخ شراء المنتج كدليل على صحة التاريخ لبدء صلاحية الضمان.
7. ان شروط واحكام هذا الضمان قابلة للتغيير دون سابق اخطار.
8. ستقوم سانفور وكافة مراكز الصيانة المعتمدة لديها بكل ما في استطاعتها لصيانة المنتج بالمرة الكاملة تحت هذا الضمان في اسرع وقت ممكن.

العناية العامة والتنظيف

- قم دائماً بإزالة القابس من المقبس قبل تنظيف الجهاز.
- لتجنب خطر التعرض لصدمة كهربائية، لا تنظف مركز المحرك أو سلك الطاقة بالماء ولا تغمرهما في الماء.
- يمكن مسح مركز المحرك بقطعة قماش مبللة قليلاً وخالية من النسالة.
- لا تستخدم مواد شديدة التأثير للتنظيف ولا تنظف الجهاز في غسالة الأطباق.
- للتنظيف بعد الاستخدام، املا وعاء الخلط بما يقرب من 100 مل من الماء الدافئ ومادة تنظيف مناسبة. -
- دع الجهاز يعمل لفترة قصيرة كما هو موضح في قسم الاستخدام. ثم اشطف وعاء الخلط والغطاء وفتحة التزويد بالماء النظيف.
- يجب تجفيف جميع الأجزاء جيداً بعد ذلك.



التخلص من المنتج بشكل صحيح

تشير هذه العلامة إلى أنه لا ينبغي التخلص من هذا المنتج مع النفايات المنزلية الأخرى في جميع أنحاء الاتحاد الأوروبي. لمنع الضرر المحتمل على البيئة أو صحة الإنسان بسبب التخلص غير المنضبط من النفايات، قم بإعادة تدويرها بشكل صحيح لتعزيز إعادة الاستخدام المستدام للموارد المادية. لإعادة جهازك المستخدم، يرجى استخدام أنظمة الإرجاع والتجميع أو الاتصال ببيع التجزئة الذي تم شراء المنتج منه. حيث يمكنه إعادة التدوير بشكل آمن للبيئة.

تحذير

- لا تغمر الجهاز في أي سائل أو ماء.
- في حالة تلف الجهاز، يرجى استبداله من قبل الشركة المصنعة أو وكيل الخدمة أو أي شخص مؤهل مماثل لتجنب المخاطر.
- عندما لا يكون الجهاز قيد الاستخدام أفضل سلك الطاقة من المقبس.
- هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص (بما في ذلك الأطفال) الذين يعانون من ضعف القدرات الجسدية أو الحسية أو العقلية أو نقص الخبرة والمعرفة إلا إذا تم تقديم الإشراف أو التعليمات بخصوص استخدام الجهاز من قبل شخص مسؤول عن سلامتهم.
- يجب مراقبة الأطفال للتأكد من أنهم لا يلعبون بالجهاز.
- قبل تشغيل الجهاز تأكد من عدم وضعه على أي سطح غير مستوي.
- لا تضع أصابعك أو يديك داخل الخلط أثناء التشغيل حفاظاً على سلامتك.

المواصفات التقنية

رقم الموديل: اس اف ٦٨٠٩ بي ار

الجهد الكهربائي: ٢٢٠-٢٤٠ فولت ~ ٥٠/٦٠ هرتز

مقدار القوة: ٦٠٠ وات

- تنبيه: الشفرة حادة للغاية. لتفادي وقوع إصابات توخى الحذر عند تنظيف الجهاز وعند إفراغ وعاء الخلط.
- لا تلمس أي أجزاء متحركة أثناء التشغيل - فقد يكون ذلك في غاية الخطورة.
- **تنبيه:** لا تضع السائل الساخن في وعاء الخلط.
- قم دائمًا بإيقاف تشغيل الجهاز وإزالة القابض من مقبض الحائط، قبل فتح الغطاء، قبل إزالة أو تركيب وعاء الخلط، قبل التنظيف، في حالة حدوث أي عطل أثناء الاستخدام وبعد الاستخدام.
- عند إزالة القابض من المقبض، لا تسحب سلك الطاقة أبدًا! امسك سلك الطاقة دائمًا! اسحب القابض دائمًا.
- **تنبيه:** أي سوء استخدام يمكن أن يسبب إصابات خطيرة. لن يتم تحمل أي مسؤولية إذا كان الضرر ناتجًا عن الاستخدام غير الصحيح أو إذا لم يتم الامتثال لهذه التعليمات.

قبل الاستخدام لأول مرة

قبل استخدام الجهاز لأول مرة يجب تنظيف وعاء الخلط والغطاء تمامًا كما هو موضح في قسم العناية العامة والتنظيف.

قبل الاستخدام

- الجهاز مصمم لاعداد كميات متوسطة من الطعام؛ يمكن تشغيله دون انقطاع لمدة أقصاها 60 ثانية وبعد ذلك يجب تبريده من خلال اطفائه.
- قبل إزالة وعاء الخلط تأكد من أن قاعدة التحكم الدوارة على الوضع 0
- ينطبق هذا أيضًا عند تركيب وعاء الخلط على المحرك.
- إذا لم يكن جهاز التحكم على وضع إيقاف التشغيل (0)، فسيبدأ المحرك بالعمل على الفور.

التشغيل

- ضع المكونات السائلة في وعاء الخلط.
- سعة الابريق 1250 مل كحد أقصى.
- لتجنب حدوث رغوة أو انسكاب محتمل عند العمل على السوائل الرغوية أو الرقيقة مثل الحليب، لا تملأ الوعاء فوق علامة 800 مل.
- لا تضع أي أشياء في وعاء الخلط أثناء تشغيل الجهاز.
- أدخل القابض في المقبض واستخدم أداة التحكم الدوارة لتحديد إعداد الطاقة المطلوب.
- تنبيه: لا تقم بالتشغيل عندما يكون وعاء الخلط فارغًا.
- لا تملأه بمواد جافة فقط مثل المكسرات واللوز وما إلى ذلك.
- بعد استخدام الخلط، قم بإيقاف التشغيل وإزالة القابض من المقبض.
- انتظر حتى يتوقف المحرك تمامًا قبل إزالة وعاء الخلط.
- انتظر دائمًا حتى يتوقف المحرك تمامًا قبل رفع الغطاء.

تعرف على الخطأ الخاص بك

تنبيه: اتبع هذه الخطوات المهمة لتجميع، شد، تركيب وعاء الخلاط بسرعة وبشكل صحيح. قد ينتج إصابة في حالة تحريك الشفرات بشكل خاطئ.

بالنسبة للخطأ: الحد الأقصى لوقت التشغيل هو 60 ثانية من كل استخدام ثم يجب أن يتم تبريد الجهاز لمدة دقيقة واحدة بعد كل استخدام.

الأجزاء

- | | | |
|-----------------|---------------------------|-------------------|
| 1. فتحة الترويد | 5. قاعدة القطع | 10. غطاء المفرومة |
| 2. الغطاء | 6. المحرك | 11. وعاء الفرغ |
| 3. وعاء الخلاط | 7. وعاء طحن المواد الجافة | 12. شفرة الفرغ |
| 4. شفرة القطع | 8. شفرة القطع | 13. قاعدة الفرغ |
| 9. قاعدة القطع | 14. أداة الكشط | |

تعليمات هامة للسلامة

- لا يجوز استخدام الجهاز من قبل الأشخاص الذين يعانون من ضعف القدرات الجسدية أو الحسية أو العقلية أو الذين يفتقرون إلى الخبرة والمعرفة إلا إذا تم الإشراف عليهم أو أعطاهم التعليمات المتعلقة باستخدام الجهاز وفهموا تمامًا جميع المخاطر واحتياطات السلامة.
- يجب عدم السماح للأطفال بتشغيل الجهاز. ويجب إبقاء الجهاز وسلك الطاقة بعيدًا عن متناول الأطفال.
- يجب عدم السماح للأطفال باللعب بالجهاز.
- تنبيه:** احتفظ بأي مواد تغليف بعيدًا عن متناول الأطفال فهذه المواد مصدر محتمل للخطر، مثل الاختناق.
- قبل استخدام الجهاز، يجب فحص الهيكل الرئيسي وأي ملحقات بشكل دقيق بحثًا عن أي عيوب.
- إذا سقط الجهاز، على سبيل المثال على سطح صلب، فلا يجب استخدامه: حتى التلف غير المرئي قد يكون له آثار سلبية على السلامة التشغيلية للجهاز.
- يجب فحص سلك الطاقة بانتظام بحثًا عن أي علامات تلف.
- في حالة العثور على مثل هذا التلف، يجب عدم استخدام الجهاز.
- يجب وضع الجهاز على سطح مستوي فقط.
- لا تسمح للجهاز أو سلك الطاقة الخاص به بالتلامس مع اللهب المكشوف أو أي أسطح ساخنة مثل الألواح الساخنة.
- لا تدع سلك الطاقة يتدلى بدون تثبيت.
- لا تترك الجهاز دون مراقبة أثناء التوصيل.
- قم دائمًا بإزالة القابس من مقبس الحائط، حتى لو تركت الغرفة لفترة قصيرة.

- فضلا اتبع التعليمات الواردة في كتيب المستخدم من أجل تركيب واستخدام المنتج
- فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب في مكان امن للرجوع اليه لاحقا
- اذا كان لديك أسئلة حول استخدام المنتج، فضلا تواصل مع خدمة العملاء عبر الإنترنت، حسب اللغة التي تحتاجها

تعرف على الخطأ الخاص بك _____ ٣.

الاجزاء _____ ٣.

تعليمات هامة للسلامة _____ ٣.

قبل الاستخدام لأول مرة _____ ٤.

قبل الاستخدام _____ ٤.

التشغيل _____ ٤.

العناية العامة والتنظيف _____ ٥.

التخلص من المنتج بشكل صحيح _____ ٥.

تحذير _____ ٥.

المواصفات التقنية _____ ٥.

تعليمات الضمان _____ ٦.

شكرا لشراءك هذا المنتج، فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب للرجوع اليه لاحقا. ان الصور الواردة في هذا الكتيب هي للتوصيح فقط، مواصفات المنتج الحقيقية هي ما تجدها على المنتج نفسه.

تعليمات وكتيب الضمان

سانفورد

تعيش تفاصيل يومك

خلاط

اس اف ٦٨٠٩ بي ار

قم بمسح رمز كيو ار فونيا ثم قم
بالتسجيل خلال 14 يوما من تاريخ الشراء
للحصول على الضمان.



قبل البدء في التركيب، اقرأ هذه التعليمات جيدا. ان اتباع هذه التعليمات
سيسهل عملية التركيب بالشكل الامن والمحيح. أترك كتيب التعليمات
بالقرب من المنتج للاطلاع عليها لاحقا.



AR ARABIC

المسلسل / دفعة
رقم: 6809112022

600 w
220-240V~ 50/60Hz



صنع في الصين | www.sanfordjapan.com | info@sanfordworld.com