


## Electric Kettle

SF3359EK

Scan this QR code and register  
for the warranty within 14 days  
of the purchase.



Before beginning installation, read these instructions carefully.  
This will simplify installation and ensure that the product is  
installed correctly and safely. Leave these instructions near the  
product after installation for future reference.

EN ENGLISH



220-240V~ 50-60Hz  
1600 Watts

Serial / Batch  
No: 3359062022



NB-0002

## TABLE OF CONTENTS

- Please obey the notices in the Instructions Manual to assemble and use the product.
- Please read and understand the Instructions Manual and keep it properly for future reference.
- If you have any question in use, please contact online service in the required language.

SAFETY INSTRUCTIONS \_\_\_\_\_ 03

OPERATION GUIDELINES \_\_\_\_\_ 04

FEATURE \_\_\_\_\_ 05

TECHNICAL SPECIFICATION \_\_\_\_\_ 05

Thank you for buying this product. Please read and understand this manual carefully and keep it properly for convenience. The pictures in this instruction manual are for reference only, specifications are subject to the physical product.

## SAFETY INSTRUCTIONS

1. This kettle is designed for domestic use only. No responsibility is accepted for damage resulting from improper use or non-compliance with the instructions.
2. The kettle is designed for heating water only. Never put any other liquid into the kettle nor should it use as another cooking appliance.
3. Before inserting the main plug into the socket whether the supply line voltage and current rating are in compliance with the rated electric parameter shown on the kettle label.
4. Do not operate the kettle with wet hands.
5. Keep children away from the kettle which is either heating or filled with hot water.
6. Prevent scalding water or steam.
7. Pour away the very first water boiled with this kettle. Then it is ready for use.
8. Do not touch any part of the kettle except the handle when the kettle is fully filled with boiling water.
9. Pour out the boiling water, all at one time, so as to enable the temperature of the kettle to decline.
10. Remove the plug from the wall socket in the following case.
  - after use
  - malfunction comes up
  - before cleaning
11. When removing the plug from the wall socket never pull on the power cord.
12. Regularly clean and scour out the kettle. But do not immerse the kettle or power base in water. As it will damage the appliance.
13. Do not expose the kettle to rain or moisture.
14. To prevent damage to the power cord, do not let it pass over sharp corners or edges.
15. Do not operate the kettle if
  - the kettle or power cord shows any signs of damage.
  - the kettle has been dropped.
16. If repairs are needed, please send the kettle to qualified personnel.
17. This appliance is not intended for use by persons (including children) with the reduced physical. Sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

18. Children should be supervised to ensure that they do not play with appliances.
19. This kettle must only be used with the power base supplied.
20. This appliance is recommended for household use only.

## **OPERATION GUIDELINES**

1. filling water
  - The capacity of filled water is limited by the ultimate line graduated on the water level scale. It should not be higher than the max line, nor lower than the minimum line.
  - On filling water, care should be taken to avoid water column flowing on the kettle,s outside surface.
2. Locating
  - Place the kettle on a suitable flat surface.
  - Never heat the kettle on any wet surface, do not allow water to penetrate the electrical parts inside the kettle.
  - Do not position the kettle on or near a hot surface or near open flames.
3. Switching on
  - Insert the main plug on the power cord into the wall socket.
  - Please take care that the power cord must be well located and can not be caught on by a passerby.
  - Push the restoring switch on
  - The red indicator lamp brights. It indicates that the kettle is heating.
4. Boiling
  - The kettle is automatically switched off several seconds after the water is boiling.
  - The red indicator lamp goes out as a switch-off.
5. Restoring
  - After the kettle has been switched off, it will take about 15 mins to cool down and the kettle can be switched on again by manual restoring.
  - If the red indicator lamp still goes out after pushing the restoring switch. It may be the case that the temperature sensing controller is still in hot condition and time must be taken to re-operating the kettle

## FEATURE

1. Immersed heating tube with a stainless steel plate under it.
2. Water level scale in metric & English systems and limit marks.
3. Three levels of appliance protection.
  - a) Temperature sensing controller-automatic switch-off when water is boiling.
  - b) Dry boiling protector-boil-dry safety cut off
  - c) Thermal fuse cut off the circuit if dry boiling protector fails.

## TECHNICAL SPECIFICATION

Wattage:1600 Watts

Power supply: 220V-240V~ 50-60Hz

Capacity:1.8 Litre



## LIMITED WARRANTY

Warranty Period	2 Years
-----------------	---------

**SANFORD** hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, **SANFORD** will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

## REGISTER YOUR NEW SANFORD PRODUCT FOR WARRANTY

The product must be registered for warranty within 14 days from the date of purchase. To register your product you'll need the model number, serial number and invoice.



### STEP: 1

Register the warranty by scanning the QR code or log on to <http://www.sanfordjapan.com/warranty.html> to access the warranty registration form.

### STEP: 2

Fill out the Warranty Registration Form and submit the application after reading and agreeing to the terms and conditions.

### STEP: 3

After successful registration, the page will display the notification message "Your entry has been submitted successfully!"

### STEP: 4

Our customer service department will verify the warranty registration within 7 days. If your warranty registration is approved, you will receive a Warranty Certificate email. Please keep the certificate to claim the warranty.

If your warranty registration is denied, you will receive an email from us explaining the reason for the rejection.

**For more information, Call Toll-Free 800-7263673 (UAE)**

**Toll-Free 1800-4251163 (INDIA), +966 559039111 (KSA)**

**+968 9525 8453 (OMAN), +974 3343 7806 (QATAR)**

**Moreover you may write to [sm-dwc@sanford-me.com](mailto:sm-dwc@sanford-me.com) and [service@sanford-me.com](mailto:service@sanford-me.com) or WhatsApp +971 543498627**

## WARRANTY INSTRUCTIONS

Thank you for purchasing **SANFORD** products, for the sake of the excellent quality of our products, we certify that **SANFORD** products are free of defects in material and workmanship and the end-user is entitled to this warranty subject to the terms and conditions listed below.

(1) The warranty will be effective only if you receive a Confirmation/Approval email and a warranty certificate from **SANFORD**.

(2) No other express warranty either written or oral is applicable to any product. THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. **SANFORD** SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS, OR ANY OTHER DAMAGES, DIRECT, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS APPLICABLE TO THIS PRODUCT.

(3) The warranty covers product failure only. If any product is found defective, **SANFORD** will at its option, repair the product in question. Any replaced parts will become the company's property.

(4) The warranty does not apply to/if (a) the accessories provided with the product. (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage from accidents, lightning, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **SANFORD**. (f) the type of the product is defaced, removed, altered, deleted, or rendered illegible.

(5) **SANFORD** will not be liable for any loss directly or indirectly caused by the breakdown of the equipment, also for any delay in repairing the set due to the non-availability of components.

(6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

(7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.

(8) **SANFORD** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.

# sanford® | Warranty Registration

## HOW TO OBTAIN THE REGISTRATION FORM?

### OPTION 1 - By scanning QR code

Scan this QR code with your smart device

Warranty Form



سأنفورڊ | تسجيل الضمان  
تعيش تفاصيل يومك

كيف تحصل على استمارة التسجيل؟

الخيار الأول - عن طريق مسح رمز كيو ار ضوئيا بواسطة هاتفك السيار



## ضمان محدد

تضمن **سانفورد**، وفقاً للشروط والأحكام الموضحة بأنه في حال تعطل هذا المنتج بسبب سوء التصنيع أو المواد المستخدمة حسب الفترة الموضحة أدناه، فإن **سانفورد** ستقوم بصيانة ذات المنتج، بما في ذلك كافة الأجزاء التي تأثرت من جراء هذا العطل دون أي رسوم مقابل الأجزاء أو العمل.

## قم بتسجيل منتج سانفورد الجديد خاصتك للحصول على الضمان

يجب تسجيل هذا المنتج للحصول على الضمان خلال 14 يوماً من تاريخ الشراء. من أجل تسجيل منتجك، عليك إرفاق رقم المنتج والرقم التسلسلي والفاتورة.

### الخطوة 1

تسجيل المنتج عبر مسح رمز الـ كيو آر ضوئياً أو الدخول على الرابط  
<http://www.sanfordjapan.com/warranty.html>  
من أجل الحصول على استمارة التسجيل



### الخطوة 2

املأ استمارة التسجيل وقم بتقديمه بعد الاطلاع والموافقة على كافة الشروط والأحكام.

### الخطوة 3

بعد إتمام عملية التسجيل بنجاح، ستظهر لك هذا الرسالة: "لقد تم التقديم بنجاح".

### الخطوة 4

سيقوم قسم خدمة العملاء بمراجعة تسجيلك خلال 7 أيام، في حال الموافقة على التسجيل الذي قمت به، ستصلك رسالة تحتوي على شهادة الضمان في بريدك الإلكتروني. فضلاً احتفظ بهذه الشهادة للحصول على الضمان. في حال قبول تسجيلك بالرفض، ستصلك رسالة لتوضيح أسباب الرفض.

للمزيد من المعلومات، يرجى الاتصال بالرقم المجاني 800 7263673 (الامارات العربية المتحدة)

الرقم المجاني 1800 4251163 (الهند)، +966 559039111 (المملكة العربية السعودية)

+968 9525 8453 (عمان)، +974 3343 7806 (قطر)

كما بإمكانك أن ترسلنا على البريد الإلكتروني: [sm-dwc@sanford-me.com](mailto:sm-dwc@sanford-me.com) وكذلك: [service@sanford-me.com](mailto:service@sanford-me.com)

أو على رقم الواتساب: +971 543498627

## تعليمات التشغيل

شكرا لشرائك منتجات سانفورد. من اجل ضمان الجودة لمنتجاتنا، نشهد بأن منتجات سانفورد خالية من العيوب في مواد التصنيع والعمل وأن المشتري له الحق في الحصول على هذا الضمان وفقا للشروط التالية:

1. يكون الضمان ساريا فقط في حال تلقيك لرسالة تأكيد/موافقة من شركة سانفورد عبر البريد الالكتروني.
2. لا يوجد ضمان صريح آخر سواء كتابي أو شفوي ينطبق على أي منتج. تقتصر مدة أي ضمانات بما في ذلك الضمان الضمني لقابلية التسويق على مدة الضمان الصريح الوارد في هذه الوثيقة. لا تتحمل شركة سانفورد مسؤولية فقدان استخدام المنتج أو الإنزعاج أو الخسارة أو أي أضرار أخرى ، مباشرة أو تكملية ، ناشئة عن استخدام أو عدم القدرة على استخدام هذا المنتج أو عن أي خرق أو انتهاك صريح أو ضمني للضمان، بما في ذلك الضمان الضمني للتسويق، ينطبق على هذا المنتج.
3. يغطي هذا الضمان فشل المنتج في العمل فقط. في حال اكتشاف ان الجهاز يحتوي على عطل ما، ستقوم سانفورد، تطوعا، بصيانة المنتج المذكور. اي اجزاء تم استبدالها تصبح ملكية خاصة بالشركة.
4. لا ينطبق هذا الضمان على أ. الملحقات التي تأتي مع المنتج ب. اعطال كهربائية. ت. عطل بسبب سوء الاستخدام أو الصيانة. ث. صيانة أو محاولة صيانة المنتج بواسطة شخص لا يملك الصلاحية. ج. عطل بسبب الحوادث أو البرق أو الماء أو الحريق أو سوء التهوية أو سوء الاستخدام أو التعديل أو لأي سبب خارج ارادة سانفورد.
5. لا تتحمل سانفورد مسؤولية فقدان بسبب تعطل الجهاز بشكل مباشر أو غير مباشر. كذلك، لأي تأخير في صيانة المنتج بسبب عدم توفر قطع الغيار.
6. يجب ارفاق فاتورة الشراء التي تحتوي على تاريخ شراء المنتج كدليل على صحة التاريخ لبدء صلاحية الضمان.
7. ان شروط واحكام هذا الضمان قابلة للتغيير دون سابق اخطار.
8. ستقوم سانفورد وكافة مراكز الصيانة المعتمدة لديها بكل ما في استطاعتها لصيانة المنتج بالمصورة الكاملة تحت هذا الضمان في اسرع وقت ممكن.

# Implementing Your expectations



**sanford**<sup>®</sup>  
TOUCHING YOUR LIFE EVERYDAY

#### 4. الغليان

- ستنطفئ الغلاية بعد عدة ثواني من الانتهاء من غلي الماء.
- سنطفئ لمبة الاشارة

#### 5. التخزين

- بعد انطفاء الغلاية ستحتاج الى 15 دقيقة حتى تبرد تماما ويمكن تسغيل الغلاية مرة اخرى بالتشغيل اليدوي
- اذا لم تضى لمخبة الشارة الحمراء ربما يعود ذلك الى ان حساس الحرارة مايزال ساخنا لذلك يجب عليك منحه بعض الوقت.

#### خصائص

1. انبوب تسخين مخبأ فوق صحن فولاذي
2. مستوى الماء موضح بالقياسات باللغة الانجليزية.
3. ثلاثة مستويات للحماية

- ا) نظام قفل الي للتحكم في حساس الحرارة عند غليان الماء
- ب) نظام حماية عند خلو الغلاية من الماء
- ج) فصل صمام منظم الحرارة عند فشل نظام الحماية عند خلو الغلاية من الماء.

#### المواصفات الفنية

- القوة الكهربائية : ١٦٠٠ واط
- التيار الكهربائي : ٢٤٠-٢٢٠ فولت ~ ٦٠-٥٠ هيرتز
- السعة : ١.٨ لتر

14. لتفادي الاضرار بسلك الكهرباء، لا تدعه يمر عبر زوايا حادة.

15. لا تشغل الغلاية اذا

- في حال تلف في سلك الكهرباء

- في حال سقوط الغلاية

16. اذا كانت الغلاية في حاجة الى صيانة، فضلاً قم بارسال الجهاز الى شخص مؤهل.

17. لا يجب استخدام الغلاية بواسطة اشخاص ذوي اعاقات جسدية او عقلية (بمافي ذلك الاطفال) او الاشخاص الذين ليس لديهم خبرة الا اذا تم الاشد عليهم.

18. يجب الاشراف على الاطفال في حال استخدامهم للغلاية وضمان عدم اللعب بها.

19. يجب توصيل الغلاية بالمقبس الرئيس للكهرباء

20. يجب استخدام الغلاية للاغراض المنزلية فقط.

#### إرشادات التشغيل

1. ملأ الماء

- الحد الأقصى للماء تم توضيحه بواسطة الخطوط المرسومة على الغلاية ولا يجب تخطيها او المبالغة في تنقيص الماء.

- كن حذرا عند ملأ الماء حتى لا ينسكب على الجدار الخارجي للغلاية.

2. الوضعية

- ضع الغلاية على سطح مستو وجاف

- لا تسخن الغلاية على سطح مبلل. لا تدع الماء يتغلغل الى الاجزاء الالكترونية داخل الغلاية.

- لا تضع على سطح ساخن او بالقرب من شعلة نار

3. التشغيل

- قم بايصال السلك بالمقبس الرئيس على الجدار.

- توخى الحذر في توثيل لسلك وتأكد من عدم اعتراضه لممر مشاة

- اضغط على زر التشغيل

ستضىء لمبة التشغيل اشارة الى ان الغلاية تعمل الان.

فضلا اقرأ التعليمات جيدا قبل التشغيل  
شكرا لاختيارك هذا الجهاز . انه واحد من مجموعة تم تصميمها بذكاء  
وتم استيعاب كل عوامل السلامة فيها ما سيجعل حياتك اكثر سهولة .  
فضلا اقرا هذه التعليمات جيدا للحصول على افضل النتائج.  
ارشادات السلامة

### تعليمات الأمان

1. تم تصميم هذه الغلاية للاستخدام المنزلي فقط. الشركة المصنعة لا تتحمل مسؤولية الاضرار الناتجة عن الاستخدام غير الصحيح او عدم الامتثال الى التعليمات.
2. تم تصميم الغلاية لتسخين الماء فقط. لا تضع ي سائل اخر داخل الغلاية ولا تستخدمها مع جهاز طبخ اخر .
3. قبل ان توصل الفيشة بالمقبس الرئيس ، تاكد من مطابقة قمية الجهد الكهربائي للغلاية والذي تم توضيح على الملصق مع الجهد الكهربائي للمصدر الرئيس للطاقة.
4. لا تشغل الغلاية ويداك مبتلتان.
5. لا تدع الاطفال بالقرب من الغلاية، وهي في حال الغليان او تحتوي على ماء يغلي.
6. ابعد عن الماء الحار او البخار.
7. اسكب الماء الذي قمت بغليه لاول مرة مستخدما هذه الغلاية بعيدا وبعد ذلك، تصبح جاهزة للاستعمال .
8. لا تحاول لمس اي جزء من الغلاية ماعدا المقبض في حال احتوائها على ماء يغلي.
9. اسكب الماء الذي يغلي دفعة واحدة خارج الغلاية لتسمح للغلاية كي تبرد.
10. افصل السلك عن الكهرباء في الحالات التالية  
- بعد الاستعمال  
- في حال حدوث تلف ما
11. لا تسحب من السلك عند فصلك له عن الكهرباء.
12. قم بتنظيف الغلاية وتطهيرها دوريا ولكن لا تغمر الغلاية او سلك الكهرباء في الماء لان ذلك يضر بالجهاز.
13. لا تعرض الغلاية للمطر او الرطوبة.

- فضلا اتبع التعليمات الواردة في كتيب المستخدم من أجل تركيب واستخدام المنتج
- فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب في مكان امن للرجوع اليه لاحقا
- اذا كان لديك أسئلة حول استخدام المنتج، فضلا تواصل مع خدمة العملاء عبر الإنترنت، حسب اللغة التي تحتاجها

**تعليمات الأمان** \_\_\_\_\_ ٣،

**إرشادات التشغيل** \_\_\_\_\_ ٤،

**المميزات** \_\_\_\_\_ ٥،

**المواصفات الفنية** \_\_\_\_\_ ٥،

شكرا لشرائك هذا المنتج. فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب للرجوع اليه لاحقا. ان الصور الواردة في هذا الكتيب هي للتوضيح فقط. مواصفات المنتج الحقيقية هي ما تجدها على المنتج نفسه.

# تعليمات وكتيب الضمان

# سانفورد

تعيش تفاصيل يومك



## غلاية كهربائية

اس اف ٣٣٥٩ اي كيه

قم بمسح رمز كيو ار ضوئيا ثم قم  
بالتسجيل خلال 14 يوما من تاريخ الشراء  
للحصول على الضمان.



قبل البدء في التركيب، اقرأ هذه التعليمات جيدا. ان اتباع هذه التعليمات  
سيسهل عملية التركيب بالشكل الامن والصحيح. اترك كتيب التعليمات  
بالقرب من المنتج للاطلاع عليها لاحقا.



AR ARABIC



NB-0002



٢٤٠-٢٢٠ فولت ~ ٦٠-٥٠ هيرتز  
١٦٠ واط

المسلسل / دفعة  
رقم: ٣٣٥٩٠٦٢٠٢٢

