

sanford[®]
TOUCHING YOUR LIFE EVERYDAY

INSTRUCTION & WARRANTY BOOKLET

ELECTRIC KETTLE

SF3363EK

Scan this QR code and register
for the warranty within 14 days
of the purchase.



Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.

EN ENGLISH



1600 Watts
220-240V~, 50/60Hz
Batch No.: 3363012023



NB-0002

www.sanfordjapan.com | info@sanfordworld.com

صنع في الصين

TABLE OF CONTENTS

- Please follow the notices in the Instructions Manual to assemble and use the product.
- Please read and understand the Instructions Manual and keep it properly for future reference.
- If you have any question in use, please contact online service in the required language.

Message	03
Before use, it shall be inspected as fellows	03
Safety Precautions	03
Designation of components	03
Product Profile	04
Usage Instructions	04
Cleaning of Electric Kettle	05
Cleaning Method	05
Safety Instructions	05

Thank you for buying this product. Please read and understand this manual carefully and keep it properly for convenience. The pictures in this instruction manual are for reference only, specifications are subject to the physical product.

MESSAGE

We appreciate your purchase of **sanford** electric kettle. Before use, please read the instruction carefully as it will help you to use the electric kettle correctly and offer you modernized enjoyment. Thank you for your cooperation.

The product is manufactured pursuant to IEC600335-1:2004 and IEC60355-15:2000 standards.


BEFORE USE, IT SHALL BE INSPECTED AS FOLLOWS

- 1、 Check and confirm if the power voltage complies with rated voltage of this product, the power socket can bear the normal load of this product and the power socket is available with reliable earthing device.
- 2、 Put this product on the flat and solid floor.
- 3、 It shall be away from fire, heating household electric appliance and combustible articles.
- 4、 It shall be put in a place beyond the reach of children and available with power wire so as to avoid scalding or electric shock.

SAFETY PRECAUTIONS

- 1、 This product is applicable for indoor water heating or boiling and not applicable for cooking or heating of any food.
- 2、 Please be aware that the risk to children or disabled persons is not considered in product design.
- 3、 It may reduce service life or cause potential risk when it is used under the environment of high temperature, much powder dust and corrosive gas, please take care.
- 4、 The product can only be used on matched base and shall not be used on the base of other product. This base cannot be used by other products.
- 5、 The connector between kettle and base cannot be used as a switch. Use the power switch properly.
- 6、 During water filling the highest water level cannot be exceeded so as to prevent steam and hot water from ejecting or overflowing out of kettle nozzle or mouth.
- 7、 This product is not provided with anti-dry burning power failure protection device, but dry burning shall be avoided as possible so as to extend service life.
- 8、 During working the metal surface on kettle body has high temperature and scalding shall be taken care.

DESIGNATION OF COMPONENTS



This photo is only for reference as an example. The physical article inside the package shall prevail.





PRODUCT PROFILE

- ◎Rapid water boiling , time and power saving
- ◎Fine filter screen is used for filtration of impurities in water
- ◎Steam induction controller, automatic power cut after water is boiling
- ◎Dry burning protection power cut can ensure safety and reliability
- ◎ It adopts high quality temperature controller
- ◎ 360° rotary base
- ◎ Noble and graceful stainless steel shell

USAGE INSTRUCTION

If the kettle is used the first time or it has not been used for long time, it is required to fill the water into the kettle to the max level, then boil the water once or twice, then empty the water so as to clean the kettle. For this moment, the water cannot be drunk.

- 1、After kettle cover is opened, remove the water kettle from the power base, fill clean water into water kettle. Take care not to exceed the maximum water level. Place the kettle cover properly and put it on the power base. The contact shall be in good condition.
- 2、Insert power wire into power supply and press switch button to light up the indicating lamp.
- 3、Lift the water kettle from the power base and empty water for drinking.
- 4、Press heat preservation switch to light up the indicating lamp, the water kettle will start heat preservation. If heat preservation is not required, press heat preservation preservation indicating lamp will go out. (Models with this function)
- 5、Lift the water kettle from the power base and empty water for drinking.
- 6、The water shall be filled according to requirement. Too much water may cause unnecessary water.
- 7、If the kettle is not used for long time, please empty the remaining water out of kettle and make it dry in the air.



This photo is only for reference as an example. The physical article inside the package shall prevail. After the water is boiled, attention shall be paid to avoid scalding while opening the kettle cover.

CLEANING OF ELECTRIC KETTLE

The kettle body and base can not be cleaned by putting them into the water or spraying the water on them.

To extend the service life of kettle, the mineral sediment inside the kettle shall be cleaned on regular basis. Before cleaning, it is required to remove the power plug and make electric kettle cool down.

Do not clean the inside of kettle and outside surface with steel wire and chemical or powder-like detergent.

CLEANING METHOD

- 1、 Fill 0.5 litre edible white vinegar into kettle and soak it inside the kettle for more than 1 hour;
- 2、 Empty the liquor out of the kettle and clean the residual sediment with wet cloth;
- 3、 Fill water into the kettle and empty the water after boiling, rinse the kettle with clean water for 4 or 5 times. The kettle can be used again;
- 4、 If necessary, repeat the above operation for several times;
- 5、 The outside of kettle can be wiped up with wet cloth;
- 6、 Remove the filter screen out of the kettle lightly, rinse with clean water or scrub with soft brush (metal brush is not allowed to use) . After drying, insert the filter screen into the mouth.

SAFETY INSTRUCTIONS

- 1- The appliances is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision of instruction.
- 2 -Children being supervised not to play with the appliance
- 3 -This appliances is intended to be used in household and similar applications
Such as:
 - staff kitchen areas in shops, offices and others working environments;
 - Farmhouses:
By clients in hotels motels and other residential type environments:
-bed and breakfast environments.

تعليمات الامان

- 1 - لا يجب استخدام الجهاز بواسطة الاشخاص ذوي الاحتياجات الخاصة (بما فيهم الاطفال) ، او الاشخاص الذين يفتقدون الى الخبرة الكافية، الا اذا اولوا الاشراف الكامل .
- 2 - يجب ان توضح التعليمات بان الاطفال لا يجب عليهم اللعب بهذا الجهاز.
- 3 - هذه الاجهزة تم تصميمها للاستخدام المنزلي او الاماكن المشابهة مثل :
 - مطبخ الموظفين
 - في المحل التجاري او المكتب او في اي بيئة مشابهة
 - منزل المزرعة :
 - غير العملاء في فندق او اي بيئة مشابهة
 - اقطار السرير او ما شابه ذلك

WARRANTY INSTRUCTIONS

Thank you for purchasing **SANFORD** products, for the sake of the excellent quality of our products, we certify that **SANFORD** products are free of defects in material and workmanship and the end-user is entitled to this warranty subject to the terms and conditions listed below.

(1) The warranty will be effective only if you receive a Confirmation/Approval email and a warranty certificate from **SANFORD**.

(2) No other express warranty either written or oral is applicable to any product. THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. **SANFORD** SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS, OR ANY OTHER DAMAGES, DIRECT, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS APPLICABLE TO THIS PRODUCT.

(3) The warranty covers product failure only. If any product is found defective, **SANFORD** will at its option, repair the product in question. Any replaced parts will become the company's property.

(4) The warranty does not apply to/if (a) the accessories provided with the product. (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage from accidents, lightning, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **SANFORD**. (f) the type of the product is defaced, removed, altered, deleted, or rendered illegible.

(5) **SANFORD** will not be liable for any loss directly or indirectly caused by the breakdown of the equipment, also for any delay in repairing the set due to the non-availability of components.

(6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

(7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.

(8) **SANFORD** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.



LIMITED WARRANTY

Warranty Period | 2 Years

SANFORD hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, **SANFORD** will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

REGISTER YOUR NEW SANFORD PRODUCT FOR WARRANTY

The product must be registered for warranty within 14 days from the date of purchase. To register your product you'll need the model number, serial number and invoice.



STEP: 1

Register the warranty by scanning the QR code or log on to <http://www.sanfordjapan.com/warranty.html> to access the warranty registration form.

STEP: 2

Fill out the Warranty Registration Form and submit the application after reading and agreeing to the terms and conditions.

STEP: 3

After successful registration, the page will display the notification message "Your entry has been submitted successfully!"

STEP: 4

Our customer service department will verify the warranty registration within 7 days, If your warranty registration is approved, you will receive a Warranty Certificate email. Please keep the certificate to claim the warranty.

If your warranty registration is denied, you will receive an email from us explaining the reason for the rejection.

For more information, Call Toll-Free 800-7263673 (UAE)

Toll-Free 1800-4251163 (INDIA), +966 559039111 (KSA)

+968 9525 8453 (OMAN), +974 3343 7806 (QATAR)

Moreover you may write to sm-dwc@sanford-me.com and service@sanford-me.com or WhatsApp +971 543498627

ضمان محدد

تضمن سانفورد، وفقا للشروط والاحكام الموضحة بأنه في حال تعطل هذا المنتج بسبب سوء التصنيع او المواد المستخدمة حسب الفترة الموضحة ادناه، فان سانفورد ستقوم بصيانة ذات المنتج، بما في ذلك كافة الاجزاء التي تأثرت من جراء هذا العطل دون أي رسوم مقابل الاجزاء او العمل.

قم بتسجيل منتج سانفورد الجديد خاصتك للحصول على الضمان

يجب تسجيل هذا المنتج للحصول على الضمان خلال ١٤ يوما من تاريخ الشراء. من اجل تسجيل منتجك، عليك ارفاق رقم المنتج والرقم التسلسلي والفاتورة.

الخطوة ١

تسجيل المنتج عبر مسح رمز الـ كيو آر ضوئيا او الدخول على الرابط
<http://www.sanfordjapan.com/warranty.html>
من اجل الحصول على استمارة التسجيل



الخطوة ٢

املء استمارة التسجيل وقم بتقديمه بعد الاطلاع والموافقة على كافة الشروط والاحكام.

الخطوة ٣

بعد اتمام عملية التسجيل بنجاح، ستظهر لك هذا الرسالة: "لقد تم التقديم بنجاح".

الخطوة ٤

سيقوم قسم خدمة العملاء بمراجعة تسجيلك خلال ٧ ايام، في حال الموافقة على التسجيل الذي قمت به، ستملك رسالة تحتوي على شهادة الضمان في بريدك الالكتروني. فضلا احتفظ بهذه الشهادة للحصول على الضمان. في حال قبول تسجيلك بالرفض، ستملك رسالة لتوضيح اسباب الرفض.

للمزيد من المعلومات، يرجى الاتصال بالرقم المجاني 800 7263673 (الامارات العربية المتحدة)

الرقم المجاني 18004251163 (الهند)، +966 559039111 (المملكة العربية السعودية)

+968 84539525 (عمان)، +974 78063343 (قطر)

كما بإمكانك ان تراسلنا على البريد الالكتروني: sm-dw@sanford-me.com وكذلك: service@sanford-me.com


أو على رقم الواتساب: +971 543498627

عن الجهاز

- غليان اسرع، توفير اكثر للوقت والطاقة.
- يوجد منقي ناعم للتخلص من الشوائب
- تحكم في مستوى البخر، قطع اتوماتيكي للطاقة بعد غليان الماء.
- حماية من التشغيل الجاف لضمان السلامة وفعالية الاستخدام
- تحكم فائق في درجة الحرارة
- قاعدة حوارة 360 درجة
- غطاء فولاذي غني لا يصدأ

كتيب المستخدم

- عند استخدامك للغلاية للمرة الاولى، او في حال لم تستخدمها لفترة من الوقت، يجب ملئها بالماء للحد الاقصى قم غلي الماء لمرة او مرتان ثم افراغ الغلاية وذلك بغرض تنظيفها. هذا الماء غير صالح للشرب.
1. بعد فتح الغطاء، قم بإزالة الغلاية من على القاعدة واملئها بماء نظيف، تأكد من عدم تجاوز الحد الاقصى لمستوى الماء، غطي الغلاية ثم ضعها على القاعدة.
 2. قم بإيصال السلك بالكهرباء ثم اضغط على مفتاح التشغيل، ستضى لمبة البيان.
 3. قم بإزالة الغلاية من على القاعدة ثم افرغ الماء للشرب.
 4. اضغط على مفتاح حفظ سخونة الماء لاضاءة لمبة البيان، ستبدأ الغلاية بحفظ حرارة الماء، اذا لم تكن في حاجة الى ذلك، اضغط على مفتاح الاحتفاظ بسخونة الماء وستطفى لمبة البيان (لهذا النوع من الغلايات).
 5. قم بإزالة الغلاية من على القاعدة واسكب الماء للشرب.
 6. يجب ملئ الماء الى المستوى الذي تحتاج اليه، زيادة حجم الماء غير الضرورية قد تؤدي الى تطاير الماء الساخن والبخر الطارق.
 7. اذا لم تكن في حاجة الى استخدام الغلاية لفترة من الوقت، فضلاقم بافراغ باقي الماء ثم جفف الغلاية بتعريضها للهواء.



هذا الشكل فقط كتوضيح، الغلاية الحقيقية التي تأتي داخل الصندوق هي الاصح، يجب عليك الانتباه جيدا لتفادي الاماية.

تنظيف غلاية كهربائية

- لا يجب تنظيف الهيكل والقاعدة بغيرهما في الماء او يرش الماء عليهما.
لاطالة عمر الغلاية، يجب ازالة الرواسب المعدنية داخل الغلاية بشكل دوري. قبل الشروع في تنظيف الغلاية والقاعدة، يجب فصل التيار الكهربائي اولا، ثم اترك الغلاية تحت تبرد تماما.
لا تنظيف الغلاية من الداخل والخارج باستخدام المنظفات المعدنية والمنظفات الكيميائية صابون البكرة.

طريقة التنظيف

1. قم باضافة 0.5 لتر من الخل الى الغلاية ثم اشط لاثلاث ساعة.
2. افرغ السائل خارج الغلاية ثم قم بإزالة الرواسب المعدنية باستخدام قطعة رطبة.
3. املا الغلاية بالماء واتركه حتى يغلي ثم افرغه، قم بشطف الغلاية، اعد هذه العملية 4 او 5 مرات، الان يمكنك استخدام الغلاية مرة اخرى.
4. عند الضرورة، قم باعادة العملية السابقة عدة مرات.
5. السطح الخارجي للغلاية يمكنك مسحه بقطعة قماش رطبة.
6. قم بإزالة المنقي خارج الغلاية برفق، اشط وامسح باستخدام فرشاة ناعمة، (لايجب استخدام فرشاة معدنية)، بعد تجفيف الغلاية، قم باعادة المنقي الى مكانه داخل الغلاية.

رسالة

نشرك على شرائك الغلاية الكهربائية احد منتجات سانفور. قبل استخدامك للجهاز فضلا اقرأ التعليمات جيدا والتي سوف تساعد على الاستعمال الامثل.

هذا المنتج مطابق للمواصفات اي اي 1:2004-600335 و اي اي سي 15:2000-60355.


قبل التشغيل، يجب عليك التأكد من التالي:

1. تأكد من تطابق الجهد الكهربائي بين الجهاز ومصدر الطاقة لديك. يجب ان يكون هناك خطا ارضيا في مقيس الكهرباء على الحائط.
2. ضع هذا الجهاز على سطح مستو وثابت
3. لا تضعه بالقرب من النار، والمعدات الاخرى التي تنتج لهمايا .
4. يجب وضعه في مكان بعيد عن متناول ايد الاطفال.

خطوات السلامة

1. هذا الجهاز تم تصميمه لتسخين الماء داخل المنزل فقط وليس في الخارج.
2. فضلا اعلم انه عند تصميم هذا الجهاز لم يضع في الاعتبار استخدامه مستقبلا بواسطة الاطفال او ذوي الاحتياجات الخاصة.
3. ان استخدام هذا الجهاز في مكان حار، او استخدام مايون الباردة او المنظفات القاشطة قد تقلل من عمره الافتراضي،
4. يجب استخدام الغلاية الكهربائية على قاعدتها المخصصة فقط. لا يجب استخدام هذه القاعدة مع اي نوع اخر من الغليات.
5. الموصل بين الغلاية والقاعدة لا يمكن استخدامه كمفتاح. فضلا استخدم مفتاح الطاقة بالشكل الصحيح.
6. عند ملئ الغلاية بالماء لايجب تخطي الحد الاقصى حتى لا يتطاير البخار ا لطارق او الماء الساخن خارج الغلاية عبر الفوهة.
7. هذا الجهاز لا يحتوي على جهاز فصل الطاقة عند تشغيل الجهاز دون ماء. لذا، يجب تجنب تشغيل الجهاز بدون ماء بقدر المستطاع.
8. عند التشغيل، يجب تجنب ملامسة السطح المعدني الخارجي حتى لا تتعرض للاحتراق.

اجزاء الغلاية



هذا الشكل فقط للايضاخ. الجهاز على الطبيعة هو الاعمج.

- فضلا اتبع التعليمات الواردة في كتيب المستخدم من أجل تركيب واستخدام المنتج
- فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب في مكان امن للرجوع اليه لاحقا
- اذا كان لديك أسئلة حول استخدام المنتج، فضلا تواصل مع خدمة العملاء عبر الإنترنت، حسب اللغة التي تحتاجها

رسالة _____ ٣.

قبل التشغيل، يجب عليك التأكد من التالي: _____ ٣.

خطوات السلامة _____ ٣.

اجزاء الغلاية _____ ٣.

عن الجهاز _____ ٤.

كتيب المستخدم _____ ٤.

تنظيف غلاية كهربائية _____ ٤.

طريقة التنظيف _____ ٤.

تعليمات الامان _____ 05

شكرا لشرايك هذا المنتج. فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب للرجوع اليه لاحقا. ان الصور الواردة في هذا الكتيب هي للتوضيح فقط. مواصفات المنتج الحقيقية هي ما تجدها على المنتج نفسه.

تعليمات
وكتيب الضمان

سانفور
تعيش تفاصيل يومك



غلاية كهربائية

اس اف ٦٣ ٣٣ اي كيه - ٢.٢ لتر

قم بمسح رمز كيو ار ضوئيا ثم قم بالتسجيل خلال ١٤ يوما من تاريخ الشراء للحصول على الضمان.



قبل البدء في التركيب، اقرأ هذه التعليمات جيدا. ان اتباع هذه التعليمات سيسهل عملية التركيب بالشكل الأيمن والصحيح. أترك كتيب التعليمات بالقرب من المنتج للاطلاع عليها لاحقا.



AR ARABIC



NB-0002



١٦٠٠ واط
٢٢٠-٢٤٠ فولت ~ ٦٠/٥٠ هرتز



www.sanfordjapan.com | info@sanfordworld.com

صنع في الصين