

# INSTRUCTION & WARRANTY BOOKLET



# Electric Kettle SF861EK



Scanning the QR code gives you access to your product's warranty registration and services.





EN ENGLISH

Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.



1100 Watts 220-240V~50/60Hz Serial / Batch No: 861032025

NB-0003

#### TABLE OF CONTENTS

- Please follow the notices in the Instructions Manual to assemble and use the product.
- Please read and understand the Instructions Manual and keep it properly for future reference.
- If you have any question in use, please contact online service in the required language.

HOW TO OPERATE THE RICE COOKER ————————————————————————————————————	03
CAUTION —	03
PRODUCT PARTS —	04
HOW TO JUDGE THE HITCH AND REPAIR IT	05

Thank you for buying this product. Please read and understand this manual carefully and keep it properly for convenience. The pictures in this instruction manual are for reference only, specifications are subject to the physical product.

#### SAFETY INSTRUCTIONS

- This kettle is designed for domestic use only. No responsibility is accepted for damage resulting from improper use or non-compliance with the instructions.
- 2. The kettle is designed for heating water only. Never put any other liquid into the kettle not should it use as another cooking appliance.
- Before inserting the main plug into the socket whether the supply line voltage and current rating are in compliance with the rated electric parameter shown on the kettle label.
- 4. Do not operate the kettle with wet hands.
- 5. Keep children away from the kettle which is either in heating or filled with hot water.
- 6. Prevent from scaling water or steam.
- 7. Pour away the very first water boiled with this kettle. Then it is ready for use.
- 8. Do not touch any part of the kettle except the handle when kettle is fully filled with boiling water.
- 9. Pour out the boiling water, all at one time, so as to enable the temperature of kettle decline.
- 10. Remove the plug from the wall socket in following case.
- · after use
- · malfunction comes up
- before cleaning
- 11. When removing the plug from the wall socket never pull on the power cord.
- 12. Regularly clean and scour out the kettle. But do not immerse the kettle or power base in water. As it will damage the appliance.
- 13. Do not expose the kettle to rain or moisture.
- 14. To prevent damage to the power cord, do not let it pass over sharp comers or edges.
- 15. Do not operate the kettle if
- the kettle or power cord show any signs of damage.
- · the kettle has been dropped.

- 16. If repairs are needed, please send the kettle to qualified personnel.
- 17. This appliance is not intended for use by persons (including children) with reduced physical. Sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction conceding use of the appliance by a person responsible for their safety.
- 18. Children should be supervised to ensure that they do not play with appliance.
- 19. This kettle must only be used with the power base supplied.
- 20. This appliance is recommended for household use only.

#### **OPERATION GUIDELINES**

#### 1. filling water

- -The capacity of filled water is limited by the ultimate line graduated on the water level scale. It should not be higher than the max line, nor lower than the minimum line.
- -On filling water, care should be taken to avoid the water column flowing on the kettle's outside surface.

### 2. Locating

Place the kettle on a suitable flat surface.

Never heat the kettle on any wet surface, and do not allow water to penetrate the electrical parts inside the kettle.

Do not position the kettle on or near a hot surface or near open flames.

#### 3. Switching on

Insert the main plug on the power cord into the wall socket.

Please take care that the power cord must be well located and cannot caught on by a passerby.

Push the restoring switch on

The red indicator lamp is bright. It indicates that the kettle is in heating.

#### 4. Boiling

The kettle is automatically switched off several seconds after the water is boiling.

The red indicator lamp goes out as a switch-off.

#### 5. Restoring

After the kettle has been switched off, it will take about 15 mines to cool down and the kettle can be switched on again by manual restoring.

If the red indicator lamp still goes out after pushing the restoring switch. It may be the case that the temperature sensing controller is still in hot condition and time must be taken for re-operating the kettle.

#### **FEATURE**

- 1. Immersed heating tube with a stainless still plate under it.
- 2. Water level scale in metric & English systems and limit marks.
- 3. Three levels of appliance protection.
- a) Temperature sensing controller-automatic switch-off when water is boiling.
- b) Dry boiling protector-boil-dry safety cut-off
- c) Thermal fuse cut off the circuit if dry boiling protector fails.

#### TECHNICAL SPECIFICATION

POWER: 1100W

Power supply: 220-240V~ 50/60Hz


Capacity: 0.5L


#### LIMITED WARRANTY

SANFORD hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, SANFORD will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

#### REGISTER YOUR NEW SANFORD PRODUCT FOR WARRANTY

Scanning the QR code gives you access to your product's warranty registration and services.





**Step 3:** Fill out the Warranty Registration Form and submit the application after reading and agreeing to the terms and conditions.

**Step 4:** After successful registration, the page will display the notification message "Your entry has been submitted successfully!"

Our customer service department will verify the warranty registration within 7 days, If your warranty registration is approved, you will receive a Warranty Certificate email. Please keep the certificate to claim the warranty.

If your warranty registration is denied, you will receive an email from us explaining the reason for the rejection.

For more information, Call Toll-Free 800-7263673 (UAE)

Toll-Free 1800-4251163 (INDIA), +966 559039111 (KSA)

+968 9525 8453 (OMAN), +974 3343 7806 (QATAR)

Moreover you may write to sm-dwc@sanford-me.com and service@sanford-me.com or WhatsApp +971 543498627



2 Years

#### WARRANTY INSTRUCTIONS

Thank you for purchasing SANFORD products, for the sake of the excellent quality of our products, we certify that **SANFORD** products are free of defects in material and workmanship, and the end-user is entitled to this warranty subject to the terms and conditions listed below.

- (1) The warranty will be effective only if you receive a Confirmation/ Approval email and a warranty certificate from **SANFORD**.
- (2) No other express warranty either written or oral is applicable to any product. THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. SANFORD SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS, OR ANY OTHER DAMAGES, DIRECT, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY IS APPLICABLE TO THIS PRODUCT.
- (3) The warranty covers product failure only. If any product is found defective, **SANFOR**D will at its option, repair the product in question. Any replaced parts will become the company's property.
- (4) The warranty does not apply to/if (a) the accessories provided with the product. (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage from accidents, lightning, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **SANFORD**. (f) the type of the product is defaced, removed, altered, deleted, or rendered illegible.
- (5) **SANFORD** will not be liable for any loss directly or indirectly caused by the breakdown of the equipment, also for any delay in repairing the set due to the non-availability of components.
- (6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eliqibility.
- (7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.
- (8) **SANFORD** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.

#### LIMITED WARRANTY

**SANFORD** hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below-specified warranty period, **SANFORD** will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

# Warranty Registr

HOW TO OBTAIN THE REGISTRATION RM?

OPTION 1 - BY SCANNING QR CCO Scan this QR code with your sr

.ce

วท

U

-بواسطة هاتفك السيار



# Implementing Your expectations



#### تعليمات التشغيل

شكرا لشرائك منتجلت سانفورد. من اجل ضمان الجودة لمنتجاتنا، نشهد بأن منتجات سانفورد ذالية من العيوب في مواد التصنيع والعمل وأن المشترك له الحق في الحصول على هذا الضمان وفقا للشروط التالية:

- 1. يكون الضمان ساريا فقط في حال تلقيك لرسالة تأكيد/موافقة من شركة سانفورد عبر البريد الاكتروني.
- 2. لا يوجد ضمان مريح اخر سواء كتابي أو شغوي ينطبق على أي منتج. تقتصر مدة أي ضمانات بما في خلك الضمان الضمني لقابلية التسويق على مدة الضمان الصريح الوارد في هذه الوثيقة. لا تتحمل شركة سانفورد مسؤولية فقدان استخدام المنتج أو الإنزعاج أو الخسارة أو أي أضرار أخرك ، مباشرة أو تكميلية ، ناشئة عن استخدام أو عدم القدرة على استخدام هذا المنتج أو عن أي خرق أو انتهاك صريح أو ضمني
  - ق. يغطي هذا الضمان فشل المنتج في العمل فقط. في حال اكتشاف ان الجهاز يحتوي على عطل ما،
     ستقوم سانفورد، تطوعاً، بصيانة المنتج المذكور. اي اجزاء تم استبدالها تصبح ملكية خاصة بالشركة.

للضمان، بها في ذلك الضمان الضمني للتسويق، ينطبق على هذا المنتج.

- 4. لا ينطبق هذا الضمان على أ. الملحقات التي تأتي مع المنتج ب. اعطال كهربائية. ت. عطل بسبب سوء الاستخدام أو الصيانة. ث. صيانة أو محلولة صيانة المنتج بواسطة شخص لا يملك الصلاحية. ج. عطل بسبب الحواحث أو البرق أو الماء أو الحريق أو سوء التهوية أو سوء الاستخدام أو التعديل أو لاك سبب خارج أراحة سائغورد.
- ق. لا تتحمل سانفورد مسؤولية الفقدان بسبب تعطل الجهاز بشكل مباشر او غير مباشر. كذلك، لاك تأخير في صيانة المنتج بسبب عدم توفر قطع الغيار.
- قاتورة الشراء التي تحتوي على تاريخ شراء المنتج كدليل على صحة التاريخ لبح، صلاحية الضمان.
  - ان شروط واحكام هذا الضمان قابلة للتغيير حون سابق اخطار.
  - ستفوم سانفورد وكافة مراكز الصيانة المعتمدة لديها بكل ما في استطاعتها لصيانة المنتج بالصورة الكاملة تحت هذا الضمان في اسرع وقت ممكن.



# مدة الضمان السنة

## ضمان محدد

تضمن **سانفورد**، وفقا للشروط والاحكام الموضحة بأنه في حال تعطل هذا المنتج بسبب سوء التصنيع او المواد المستخدمة حسب الفترة الموضحة ادناه، فان **سانفورد** ستقوم بصيانة ذات المنتج، بما في ذلك كافة الاجزاء التي تأثرت من جراء هذا العطل دون أي رسوم مقابل الاجزاء او العمل.

# قم بتسجيل منتج سانفورد الجديد خاصتك للحصول على الضمان

يهندك مسح رمز الاستجابة السريعة إمكانية الوصول إلى تسجيل الضمان الخاص بهنتجك وخدمات الصيانة.

الخطوة ا تسجيل المنتج عبر مسج رمز الـ كيو ار ضونيا او الدخول على الرابط http://www.sanfordjapan.com/warranty.html من اجل الحصول على استمارة التسجيل الخطوة ۲ املء استمارة التسجيل وقم بتقديمه بعد الاطلاع والموافقة على كافة الشروط والاحكام.

الخطوة  $^{\sf M}$  بعد اتمام عملية التسجيل بنجاح، ستظهر لك هذا الرسالة: "لقد تم التقديم بنجاج".

الخطوة  $^3$  سيقوم قسم خدمة العملاء بمراجعة تسجيلك خلال  $^{
m V}$  ايام، في حال الموافقة على التسجيل الذي قمت به، ستصلك رسالة تحتوي على شهادة الضمان في بريدك الالكتروني. فضلا احتفظ بهذه الشهادة للحصول على الضمان. في حال قوبل تسجيلك بالرفض، ستصلك رسالة لتوضيح اسباب الرفض.

للمزيد من المعلومات، يرجى الاتصال بالرقم المجاني 800 7263673 ( الامارات العربية المتحدة) الرقم المجاني 18004251163 (المند)، 966 55903911 (المملكة العربية السعودية) 968 9525 8453 464 ( عمان )، 780 3343 9744 (قطر)

كما بامكانك ان تراسلنا على البريد الالكتروني : sm-dwc@sanford-me.com وكذلك: service@sanford-me.com أو على رقم الواتساب: 971543498627+

## 4. الغلبان

- يتم إيقاف تشغيل الغلاية تلقائيًا بعد عدة ثواني من غليان الماء.
  - ينطفئ مصباح المؤشر الأحمر عند إيقاف التشغيل،

## 5. الاستخدام مرة أخرى

- بعد إيقاف تشغيل الغلاية، سيستغرق الأمر حوالي 15 دقيقة حتى تبرد ويمكن تشغيل الغلاية مرة أذك.
- إذا ظل مصباح المؤشر الأحمر ينطفى بعد الضغط على مفتاح التشغيل. قد يكون الأمر أن وحدة التحكم في استشعار درجة الحرارة لا تزال في حالة ساخنة ويجب الانتظار لبعض الوقت لإعادة تشغيل الغلابة.

# المميزات

- 1. أداة تسخين مثبتة مع لوح من الستانلس ستبل تحتو.
- 2. مقياس منسوب المياه بالأنظمة المترية والإنجليزية وعلامات الحدود.
  - 3. ثلاثة مستويات لحماية الجهاز.
- A) التحكم في درجة الحرارة: إيقاف التشغيل التلقائي عند غليان الماء.
- B) الحماية من الغليان الجاف: عند الغليان الجاف بدون وجود الماء يتم ايقاف التشغيل تلقائيا.
- C) في حالة فشل نظام الحماية من الغليان الجاف يتم فصل الدائرة الكهربائية عن طريق انصهار الفيوز الكهربائي.

# المواصفات التقنية

- الطاقة: 1100 وات
- مصدر الطاقة: 220-240 فولت ~ 60/50 هرتز
  - السعة: 5.0 لتر

- 15. لا تقم بتشغيل الغلاية إذا ظهرت أي علامات للتلف على الغلاية أو سلك الطاقة أو اذا سقط الجهاز. 16. اذا كانت هناك حاحة الى اصلاحات، برحى اسلال الغلاية الى الفنيين المؤهلين.
- 17. هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص (بما في ذلك الأطفال) ذوي الإعاقة الجسدية.
  - ... القدرات الحسية أو العقلية المنخفضة، أو ممن لديهم نقص الخبرة والمعرفة، ما لم يتم الإشراف علىهم أو تزويدهم بتعليمات تسمح لهم باستخدام الحهاز من قبل شخص مسؤول عن سلامتهم.
    - 18. يجب مراقبة الأطفال للتأكد من عدم عبثهم بالجهاز.
    - 19. يجب استخدام هذه الغلاية فقط مع قاعدة الطاقة المتوفرة.
      - 20. يوصى باستخدام هذا الجهاز للاستخدام المنزلي فقط.

# إرشادات التشغيل:

## 1. تعبئة الماء

- -سعة الماء محدودة بالخط المتدرج على مقياس منسوب الماء. ولا ينبغي أن يكون أعلى من خط الحد الأقصى، ولا أقل من خط الحد الأدني.
  - عند تعبئة الماء، يجب توخي الحذر لتجنب تدفق الماء على السطح الخارجي للغلاية.

# 2. تحديد الموقع

- ضع الغلاية على سطح مستو مناسب.
- لا تقم أبدًا بتسخين الغلاية على أي سطح مبلل، ولا تسمح للماء باختراق الأجزاء الكهربائية الموجودة
  - داخل الغلاية. الانتخام الخلالة على برواج برياخ أو القربي أو أو القربي اللحرب اللكثرة غ
    - لا تضع الغلاية على سطح ساذن أو بالقرب منه أو بالقرب من اللهب المكشوف.

# 3.التشغيل

- أدخل القابس الرئيسي الموجود على سلك الطاقة في مقبس الحائط.
- يرجى الحرص على أن يكون سلك الطاقة في مكان جيد ولا يمكن أن يمسك به أحد المارة.
- اضغط على مفتاح التشغيل، وسيشير مصباح المؤشر الاحمر الساطع على أن الغلاية في وضع التسخين.

## تعليمات الأمان والسلامة

- 1. تم تصميم هذه الخلاية للاستخدام المنزلي فقط. لا يتم قبول أي مسؤولية عن الأضرار الناجمة عن الاستخدام غير السلام أو عدم الالتزام بالتعليمات.
  - الغلاية مصممة لتسخين الماء فقط. لا تضع أبدًا أي سائل أخر فيها ولا ينبغي استخدامها كجهاز طهى أخر.
    - قبل إدخال القابس الرئيسي في المقبس، تأكد من توافق الجهد الكهربائي لديك مع ما هو موضح على الحهاز.
      - 4. لا تقم يتشغيل الغلاية بأيدي مبتلة.
      - 5. أبعد الأطفال عن الغلاية التي تكون اما قيد التسخين أو مملوءة بالماء الساخن.
      - 6. بحب الحذر من الماء المغلى والبخار.
  - 7. تخلص من الماء المغلي للمرة الأولى عند استخدام الغلاية الجديدة. ثم يصبح جاهزًا للاستخدام الطبيع، ،،
  - 8. لا تلمس أي جزء من الغلاية باستثناء المقبض عندما تكون الغلاية مملوءة بالكامل بالماء المغلي.
    - 9. قم بسكب الماء المغلي دفعة واحدة حتى تنخفض درجة حرارة الغلاية.
      - 10. قم بإزالة القابس من مقبس الحائط في الحالات التالية:
        - •بعد الاستعمال
          - ظهور عطل
          - •قىل التنظيف
      - 11. عند إزالة القابس من مقبس الحائط، لا تسحب سلك الطاقة أبدًا.
  - 12. قم بتنظيف الغلاية بانتظام. ولا تغمر الغلاية أو قاعدة الطاقة في الماء. لانها سوف تلحق الضرر بالحهان
    - 13. لا تعرض الغلاية للمطرأة الرطوية.
    - 14. لهنع تلف سلك الطاقة، لا تسهج له بالهرور فوق الزوايا أو الحواف الحادة.

## قائمة المحتوبات

- فصلا اتبع التعليمات الواردة في كتيب المستخدم من أجل تركيب واستخدام المنتج
- فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب في مكان امن لا دوء الله لاحقا
- اذا كان لديك أسئلة حول استخدام المنتج، فضلا تواصل مع خدمة العملاء عبر الإنترنت، حسب اللغة التي ، تحتاحها

شكرا لشرائك هذا المنتج. فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب للرجوع اليه لاحقا. ان الصور الواردة في هذا الكتيب هي للتوصيح فقط. مواصفات المنتج الحقيقية هي ما تجدها على المنتج نفسه.







# غلايـة كهربائية

اس اف ۱۸۱ اي کیه



يمنحك مسح ر مز الاستجابة السريعة امكانية الوصول إلى تسجيل الضمان الخاص يمنتحك وخدمات الصيانة.





قبل البدء في التركيب، اقرأ هذه التعليمات جيدا. ان اتباع هذه التعليمات سيسهل عملية التركيب بالشكل الأمن والصحيح. أترك كتيب التعليمات بالقرب من المنتج للاطلاع عليها لاحقا.

AR ARABIC



Serial / Batch No: 861032025

1100 Watts 220-240V~50/60Hz

