


Stand Fan

SF902SFN

Scanning the QR code gives you
access to your product's warranty
registration and services.



Before beginning installation, read these instructions carefully.
This will simplify installation and ensure that the product is
installed correctly and safely. Leave these instructions near the
product after installation for future reference.

EN ENGLISH



60 Watts
220-240V~, 50/60Hz
Batch No.: 902032024




TABLE OF CONTENTS

- Please obey the notices in the Instructions Manual to assemble and use the product.
- Please read and understand the Instructions Manual and keep it properly for future reference.
- If you have any question in use, please contact online service in the required language.

PARTS	3
WARNING	3
COLUMN ASSEMBLY INSTRUCTIONS	4
FAN BODY ASSEMBLY INSTRUCTIONS	4
FAN OPERATING INSTRUCTION	4

Thank you for buying this product. Please read and understand this manual carefully and keep it properly for convenience. The pictures in this instruction manual are for reference only, specifications are subject to the physical product.

PARTS



Read Rules for Safe Operation and Instructions Carefully.

WARNING

1. Do not leave the fan running unattended.
2. Keep electrical appliances out of reach from children or infirm persons. Do not let them use the appliances without supervision.
3. Ensure that the fan is switched off from the supply mains before removing the guard.
4. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
5. This appliance is not intended for use by persons (including children)

with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

6. Children should be supervised to ensure that they do not play with the appliance.

COLUMN ASSEMBLY INSTRUCTIONS

Take the base and column parts from the packing box and loose the plastic nut. Fix the column on the base plate using the plastic nut. Unscrew the height adjusting knob. Mount the column ornament, and move to the desired height. Then screw the height adjusting knob to tighten the extension pole.

FAN BODY ASSEMBLY INSTRUCTIONS

1. Unscrew the spinner clockwise and the nut counter-clockwise to remove both of them.
2. Set the rear guard in the proper position with handle up.
3. Screw on plastic nut tightly to attach rear guard.
4. Discard plastic sleeve on motor shaft.
5. Install the blade onto the motor shaft until it reaches the retaining pin.
6. Screw spinner onto motor shaft counter clockwise to blade.
7. Press the rim of the rear guard onto the front guard until the rear guard is properly fitted.
8. Secure both guards firmly by tightening the fan guard then close easy clip.

FAN OPERATING INSTRUCTIONS

1. Once the fan has been assembled correctly connect the mains plug to the mains socket.
2. To turn fan on press "ON/SPEED" on the control box or on the remote.
* When fan is on, it will start in low speed and the display shows "LOW". Repeatedly press "ON/SPEED" to select the desired fan speed from LOW to HIGH.
3. To turn fan off press "OFF" on the control box or on the remote.

4. To make/ stop the fan oscillate press "SWING" repeatedly

5. Tilt adjusting:

To adjust the air flow upward or downward, push the guard lightly to the desired direction.

6. Mode

Press "MODE" repeatedly to select the desired wind mode. The corresponding light will illuminate to show what wind mode you choose.
Normal wind Natural wind Sleep wind

7. Timer

You can set the fan to automatically turn itself off within a desired time period from 0.5 to 7.5 hours.

This appliance is not intended for use by persons (including children) with reduced. Physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

sanford® | Warranty Registration

HOW TO OBTAIN THE REGISTRATION FORM?

OPTION 1 - By scanning QR code

Scan this QR code with your smart device

Warranty Form



سأنفورڊ | تسجيل الضمان
تعيش تفاصيل يومك

كيف تحصل على استمارة التسجيل؟

الخيار الأول - عن طريق مسح رمز كيو ار ضوئيا بواسطة هاتفك السيار

WARRANTY INSTRUCTIONS

Thank you for purchasing **SANFORD** products, for the sake of the excellent quality of our products, we certify that **SANFORD** products are free of defects in material and workmanship and the end-user is entitled to this warranty subject to the terms and conditions listed below.

(1) The warranty will be effective only if you receive a Confirmation/Approval email and a warranty certificate from **SANFORD**.

(2) No other express warranty either written or oral is applicable to any product. THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY OF HEREIN. **SANFORD** SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS, OR ANY OTHER DAMAGES, DIRECT, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS APPLICABLE TO THIS PRODUCT.

(3) The warranty covers product failure only. If any product is found defective, **SANFORD** will at its option, repair the product in question. Any replaced parts will become the company's property.

(4) The warranty does not apply to/if (a) the accessories provided with the product. (b) cosmetic damage (c) damage due to improper use or maintenance (d) repair or attempted repair of the product by non-authorized persons (e) damage from accidents, lightning, water, fire, improper ventilation, misuse, alteration, or any cause beyond the control of **SANFORD**. (f) the type of the product is defaced, removed, altered, deleted, or rendered illegible.

(5) **SANFORD** will not be liable for any loss directly or indirectly caused by the breakdown of the equipment, also for any delay in repairing the set due to the non-availability of components.

(6) The purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

(7) The warranty terms and conditions of this warranty certificate would be revised without prior notice.

(8) **SANFORD** and its authorized service centers will make every effort to carry out expeditious repairs under this warranty as soon as possible.



LIMITED WARRANTY

Warranty Period	2 Years
-----------------	---------

SANFORD hereby warrants, subject to the terms and conditions herein below set forth that should this product become defective by reason of improper workmanship or material during the below specified warranty period, **SANFORD** will repair the same, effecting all necessary parts replacement, without charge for either parts or labour.

REGISTER YOUR NEW SANFORD PRODUCT FOR WARRANTY

Scanning the QR code gives you access to your product's warranty registration and services.



STEP: 1

Register the warranty by scanning the QR code or log on to <http://www.sanfordjapan.com/warranty.html> to access the warranty registration form.

STEP: 2

Fill out the Warranty Registration Form and submit the application after reading and agreeing to the terms and conditions.

STEP: 3

After successful registration, the page will display the notification message "Your entry has been submitted successfully!"

STEP: 4

Our customer service department will verify the warranty registration within 7 days. If your warranty registration is approved, you will receive a Warranty Certificate email. Please keep the certificate to claim the warranty.

If your warranty registration is denied, you will receive an email from us explaining the reason for the rejection.

For more information, Call Toll-Free 800-7263673 (UAE)

Toll-Free 1800-4251163 (INDIA), +966 559039111 (KSA)

+968 9525 8453 (OMAN), +974 3343 7806 (QATAR)

Moreover you may write to sm-dwc@sanford-me.com and service@sanford-me.com or WhatsApp +971 543498627

sanford[®]
TOUCHING YOUR LIFE EVERYDAY

Implementing
Your expectations



ضمان محدد

تضمن **سانفورد**، وفقا للشروط والاحكام الموضحة بأنه في حال تعطل هذا المنتج بسبب سوء التصنيع او المواد المستخدمة حسب الفترة الموضحة ادناه، فإن **سانفورد** ستقوم بصيانة ذات المنتج، بما في ذلك كافة الاجزاء التي تأثرت من جراء هذا العطل دون أي رسوم مقابل الاجزاء او العمل.

قم بتسجيل منتج سانفورد الجديد خاصتك للحصول على الضمان

بمنتك مسح رمز الاستجابة السريعة إمكانية الوصول إلى تسجيل الضمان الخاص بمنتجك وخدمات الصيانة.

الخطوة ١

تسجيل المنتج عبر مسح رمز الكيو آر ضوئيا او الدخول على الرابط
<http://www.sanfordjapan.com/warranty.html>
من اجل الحصول على استمارة التسجيل



الخطوة ٢

املء استمارة التسجيل وقم بتقديمه بعد الاطلاع والموافقة على كافة الشروط والاحكام.

الخطوة ٣

بعد اتمام عملية التسجيل بنجاح، ستظهر لك هذا الرسالة: "لقد تم التقديم بنجاح".

الخطوة ٤

سيقوم قسم خدمة العملاء بمراجعة تسجيلك خلال ٧ ايام، في حال الموافقة على التسجيل الذي قمت به، ستملك رسالة تحتوي على شهادة الضمان في بريدك الالكتروني، فضلا احتفظ بهذه الشهادة للحصول على الضمان.
في حال قبول تسجيلك بالرفض، ستملك رسالة لتوضيح اسباب الرفض.

للمزيد من المعلومات، يرجى الاتصال بالرقم المجاني 800 7263673 (الامارات العربية المتحدة)

الرقم المجاني 18004251163 (الهند)، +966 559039111 (المملكة العربية السعودية)

+968 95258453 (عمان)، +974 3343 7806 (قطر)

كما بإمكانك ان تراسلنا على البريد الالكتروني: sm-dwc@sanford-me.com وكذلك: service@sanford-me.com

أو على رقم الواتساب: +971 543498627

تعليمات التشغيل

شكرا لشرائك منتجات سانفورد. من اجل ضمان الجودة لمنتجاتنا، نشهد بأن منتجات سانفورد خالية من العيوب في مواد التصنيع والعمل وأن المشتري له الحق في الحصول على هذا الضمان وفقا للشروط التالية:

1. يكون الضمان ساريا فقط في حال تلقيك لرسالة تأكيد/موافقة من شركة سانفورد عبر البريد الالكتروني.
2. لا يوجد ضمان صريح آخر سواء كتابي أو شفوي ينطبق على أي منتج. تقتصر مدة أي ضمانات بما في ذلك الضمان الضمني لقابلية التسويق على مدة الضمان الصريح الوارد في هذه الوثيقة. لا تتحمل شركة سانفورد مسؤولية فقدان استخدام المنتج أو الإنزعاج أو الخسارة أو أي أضرار أخرى ، مباشرة أو تكميلية ، ناشئة عن استخدام أو عدم القدرة على استخدام هذا المنتج أو عن أي خرق أو انتهاك صريح أو ضمني للضمان، بما في ذلك الضمان الضمني للتسويق، ينطبق على هذا المنتج.
3. يغطي هذا الضمان فشل المنتج في العمل فقط. في حال اكتشاف ان الجهاز يحتوي على عطل ما، ستقوم سانفورد، تطوعا، بصيانة المنتج المذكور. اي اجزاء تم استبدالها تصبح ملكية خاصة بالشركة.
4. لا ينطبق هذا الضمان على أ. الملحقات التي تأتي مع المنتج ب. اعطال كهربائية. ت. عطل بسبب سوء الاستخدام أو الصيانة. ث. صيانة أو محاولة صيانة المنتج بواسطة شخص لا يملك الصلاحية. ج. عطل بسبب الحوادث أو البرق أو الماء أو الحريق أو سوء التهوية أو سوء الاستخدام أو التعديل أو لأي سبب خارج ارادة سانفورد.
5. لا تتحمل سانفورد مسؤولية فقدان بسبب تعطل الجهاز بشكل مباشر أو غير مباشر. كذلك، لأي تأخير في صيانة المنتج بسبب عدم توفر قطع الغيار.
6. يجب ارفاق فاتورة الشراء التي تحتوي على تاريخ شراء المنتج كدليل على صحة التاريخ لبدء صلاحية الضمان.
7. ان شروط واحكام هذا الضمان قابلة للتغيير دون سابق اخطار.
8. ستقوم سانفورد وكافة مراكز الصيانة المعتمدة لديها بكل ما في استطاعتها لصيانة المنتج بالصورة الكاملة تحت هذا الضمان في اسرع وقت ممكن.

هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص ذوي الاحتياجات الخاصة والقدرات الجسدية أو الحسية أو العقلية ، أو نقص الخبرة وقليالي الخبرة (بما في ذلك الأطفال)، ما لم يتم منحهم الإشراف أو التوجيه فيما يتعلق باستخدام الجهاز من قبل شخص مسؤول عن سلامتهم.

يجب مراقبة الأطفال للتأكد من أنهم لا يلعبون بالجهاز.

في حالة تلف سلك الإمداد، يجب استبداله من قبل الشركة المصنعة أو وكيل الخدمة التابع لها أو بواسطة شخص مؤهل لتجنب الخطر.

5. لا يجب استخدام هذا الجهاز بواسطة الأشخاص ذوي القصور الجسدي أو الحسي (بما في ذلك الأطفال)
إلا اذا اولوا الاشراف اللازم من قبل اشخاص مسؤولين عن سلامتهم مع توضيح طريقة التشغيل ومخاطر الاستخدام الخاطئ
6. يجب الاشراف على الأطفال لضمان عدم اللعب بهذا الجهاز

تعليمات تركيب العمود

خذ أجزاء القاعدة والعمود من صندوق التعبئة وفك المامولة البلاستيكية. ثبت العمود الموجود على لوحة القاعدة باستخدام المامولة البلاستيكية. فك مقبض ضبط الارتفاع. قم بتركيب زخرفة العمود ، وانتقل إلى الارتفاع المطلوب. اضبط الارتفاع باستخدام البرغي لتثبيت عمود التمديد.

تعليمات تجميع هيكل المروحة

1. قم بفك البرغي الدوار في اتجاه عقارب الساعة والمامولة عكس اتجاه عقارب الساعة لإزالة التهمة.
2. ضع الغطاء الخلفي في الموضع المناسب مع رفع المقبض.
3. اربط البرغي على المامولة البلاستيكية بإحكام لتثبيت الغطاء الخلفي.
4. تجاهل الغلاف البلاستيكي على عمود المحرك.
5. قم بتثبيت الشفرة على عمود المحرك بادخالها حتى تصل إلى دبوس التثبيت.
6. ثبت البرغي الدوار على عمود المحرك بعكس اتجاه عقارب الساعة للشفرة.
7. اضغط على حافة الغطاء الخلفي على الوافي الأمامي حتى يتم تركيب الوافي الخلفي بشكل صحيح.
8. قم بتأمين كلا الغطائين بإحكام عن طريق شد وافي المروحة ثم إغلاق المشبك السهل.


تعليمات تشغيل المروحة

1. بمجرد تجميع المروحة بشكل صحيح ، قم بتوصيل قابس التيار الكهربائي بمقبس التيار الرئيسي.
2. لتشغيل المروحة اضغط على "ON / SPEED" في لوحة التحكم أو على جهاز التحكم عن بعد.
- * عند تشغيل المروحة ، ستبدأ بسرعة منخفضة وتظهر الشاشة "LOW". اضغط بشكل متكرر على "ON / SPEED" لتعديل سرعة المروحة المرغوبة من LOW إلى HIGH.
3. لإيقاف تشغيل المروحة اضغط على "OFF" في لوحة التحكم أو على جهاز التحكم عن بعد.
4. لجعل / إيقاف المروحة من الدوران اضغط على "SWING" بشكل متكرر
5. ضبط الإمالة:
6. لضبط تدفق الهواء لأعلى أو لأسفل، ادفع الوافي برفق إلى الاتجاه المطلوب.
7. الوضع
8. اضغط على "MODE" بشكل متكرر لتحديد وضع الرياح المطلوب. سيضيء الضوء المقابل لإظهار وضع الرياح الذي تختاره. الرياح العادية الرياح الطبيعية رياح النوم
9. الموقت
10. يمكنك ضبط المروحة لإيقاف نفسها تلقائيًا خلال الفترة الزمنية المرغوبة من 0.5 إلى 7.5 ساعة.

فضلا اقرأ هذا الكتيب جيدا واحتفظ به لمراجعتك في المستقبل

أسماء الأجزاء

1. الغطاء الأمامي
2. صامولة التثبيت
3. شفرة المروحة
4. صامولة القفل
5. الغطاء الخلفي
6. عمود المحرك
7. هيكل المحرك
8. العنق
9. صندوق التحكم
10. برغي
11. القطب الداخلي
12. حلقة تعديل الارتفاع
13. القطب الخارجي
14. القاعدة
15. قفل الرافعة
16. جهاز تحكم عن بعد



تنبيه

اقرأ تعليمات التشغيل من أجل الاستخدام الآمن.

تحذير

1. لا تترك المروحة تعمل دون إشراف
2. احتفظ بالأجهزة الكهربائية بعيدا عن متناول أيدي الأطفال وذوي الهمّة
3. تأكد من فصل السلك عن التيار أولا قبل إزالة الغطاء الأمامي
4. في حال تلف سلك الكهرباء، يجب استبداله بواسطة الشركة المصنعة أو عبر أحد مراكز الصيانة المعتمدة أو بواسطة شخص ذو خبرة لتفادي التعرض للإصابة


- فضلا اتبع التعليمات الواردة في كتيب المستخدم من أجل تركيب واستخدام المنتج
- فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب في مكان امن للرجوع اليه لاحقا
- اذا كان لديك أسئلة حول استخدام المنتج، فضلا تواصل مع خدمة العملاء عبر الإنترنت، حسب اللغة التي تحتاجها

12	أسماء الأجزاء
12	تنبيه
12	تحذير
13	تعليمات تركيب العمود
13	تعليمات تجميع هيكل المروحة
13	تعليمات تشغيل المروحة

شكرا لشرائك هذا المنتج. فضلا اقرأ مع الفهم كافة التعليمات الواردة في كتيب المستخدم واحتفظ بالكتيب للرجوع اليه لاحقا. ان الصور الواردة في هذا الكتيب هي للتوضيح فقط. مواصفات المنتج الحقيقية هي ما تجدها على المنتج نفسه.

تعليمات
وكتيب الضمان

سانفورد
تعيش تفاصيل يومك



مروحة قائمة اس اف ٩٠٢ اس اف ان

يمنحك مسح رمز الاستجابة السريعة
إمكانية الوصول إلى تسجيل الضمان الخاص
بمنتجك وخدمات الصيانة.



قبل البدء في التركيب، اقرأ هذه التعليمات جيدا. ان اتباع هذه التعليمات
سيسهل عملية التركيب بالشكل الامن والصحيح. أترك كتيب التعليمات
بالقرب من المنتج للاطلاع عليها لاحقا.



AR ARABIC



٦٠ واط
220-240V~, 50/60Hz
Batch No.: 902032024



www.sanfordjapan.com | info@sanfordworld.com | صنع في الصين